


# FUEL SYSTEM

Ref No.	Part Number	Description	Qty	Remarks
1	6E5-24304-10-00	FUEL PIPE JOINT COMP. 1	1	
2	97313-06020-00	BOLT, HEXAGON	1	
3	92990-06600-00	.WASHER, PLATE	1	
4	6G5-24313-00-00	PIPE 3	1	
5	90465-11M10-00	CLAMP	10	
6	6E5-24560-00-00	FILTER ASSY	1	
7	655-24521-01-00	. CUP, FILTER	1	
8	93210-37M25-00	. O-RING	1	
9	6F5-24563-00-00	. ELEMENT, FILTER	1	
10	655-24564-00-00	. GASKET	1	
11	648-24566-01-00	BRACKET, FILTER	1	
12	97313-06014-00	BOLT, HEXAGON	1	
13	92995-06100-00	WASHER, SPRING	1	
14	95333-08600-00	NUT	1	
15	6G5-24314-00-00	PIPE 4	1	
16	6E5-24410-03-00	FUEL PUMP ASSY	2	
17	98580-05035-00	. SCREW, PAN HEAD	6	
18	92990-05600-00	. WASHER, PLATE	6	
19	6E5-24413-00-00	. BODY 2	2	
20	6E5-24471-00-00	. DIAPHRAGM	2	


CONTINUED ON NEXT FRAME >



# FUEL SYSTEM

Ref No.	Part Number	Description	Qty	Remarks
21	6E5-24435-00-00	. GASKET, BODY 2	2	
22	6E5-24411-00-00	. DIAPHRAGM	2	
23	648-24424-00-00	. SEAT, SPRING	2	
24	6E5-24423-00-00	. SPRING, DIAPHRAGM	2	
25	6E5-24434-02-00	. GASKET, BODY	2	
26	6A0-24421-01-00	. VALVE, CHECK	8	
27	98580-03008-00	. SCREW, PAN HEAD	8	
28	98813-03100-00	. NUT	8	
29	650-24431-A0-00	GASKET, FUEL PUMP 1	2	
30	97313-06050-00	BOLT	4	
31	92990-06600-00	. WASHER, PLATE	4	
32	6E5-24315-00-00	PIPE 5	1	
33	6E5-24378-00-00	PIPE, JOINT 3	1	
34	6E5-24316-00-00	PIPE 6	2	
35	6G5-24315-00-00	PIPE 5	1	
36	6G5-24376-00-00	PIPE, JOINT 1	1	
37	6G5-24377-00-00	PIPE, JOINT 2	1	
38	6G5-24317-01-00	PIPE 7	1	
39	6G5-24318-00-00	PIPE, OVERFLOW	2	
40	6G5-24319-00-00	PIPE, OIL	1	

CONTINUED ON NEXT FRAME >



# FUEL SYSTEM

Ref No.	Part Number	Description	Qty	Remarks
41	90465-11M10-00	CLAMP	10	

