





REPAIR KIT 1

Ref No.	Part Number	Description	Qty	Remarks
1	6H4-W0001-01-00	POWERHEAD GASKET KIT	1	
2	6H4-11181-A0-00	. GASKET, CYLINDER HEAD 1	1	
3	6H4-11193-00-00	. GASKET, HEAD COVER 1	1	
4	90430-14115-00	. GASKET	1	
5	6J8-12414-A0-00	. GASKET, COVER	1	
6	6H4-41114-A0-00	. GASKET, EXHAUST COVER	2	
7	6H4-15369-A1-00	. GASKET, OIL SEAL HOUSING	1	
8	93101-16M36-00	. OIL SEAL	2	
9	93102-25M28-00	. OIL SEAL	1	
10	93210-57M09-00	. O-RING	1	
11	6H4-13621-A1-00	. GASKET, VALVE SEAT	2	
12	6H4-14198-00-00	. GASKET	1	
13	6H3-14457-01-00	. SEAL	3	
14	6G1-14984-00-00	. O-RING	3	
15	93210-37M25-00	. O-RING	1	
16	650-24431-A0-00	. GASKET, FUEL PUMP 1	1	
17	6H4-45113-A0-00	. GASKET, UPPER CASING	1	
18	6H4-W0093-01-00	CARBURETOR REPAIR KIT	1	
19	6H4-14198-00-00	. GASKET	1	
20	676-14966-00-00	. CAP	2	

CONTINUED ON NEXT FRAME >



REPAIR KIT 1

Ref No.	Part Number	Description	Qty	Remarks
21	6H3-14590-00-00	. NEEDLE VALVE ASSEMBLY	3	
22	663-14159-00-00	. .CLIP	3	
23	676-14186-00-00	. PIN, FLOAT	3	
24	6G1-14985-00-00	. FLOAT	3	
25	688-14548-00-00	. PIN, FLOAT ARM	3	
26	6G1-14984-00-00	. O-RING	3	
27	97980-04114-00	. .SCREW, WITH WASHER	3	
28	93210-04230-00	. O-RING	3	
29	663-14126-00-00	. GASKET	3	
30	688-14126-00-00	. GASKET	3	
31	692-14923-00-00	. SCREW, PILOT	3	
32	93210-15M52-00	. O-RING	3	