


FUEL SYSTEM

Ref No.	Part Number	Description	Qty	Remarks
1	6R3-24313-10-00	PIPE 3 (L:1620)	1	UR LONG
1	6R3-24313-20-00	PIPE 3 (L2820)	1	UR ULTRA LONG
2	6R3-24377-00-00	PIPE, JOINT 2	1	
3	90465-11M10-00	.CLAMP	3	
4	6E5-24560-00-00	FILTER ASSY	1	
5	655-24521-01-00	. CUP, FILTER	1	
6	93210-37M25-00	. O-RING	1	
7	6F5-24563-00-00	. ELEMENT, FILTER	1	
8	655-24564-00-00	. GASKET	1	
9	6E5-24566-00-00	BRACKET, FILTER	1	
10	97313-06014-00	BOLT, HEXAGON	1	
11	92995-06100-00	WASHER, SPRING	1	
12	95380-08600-00	NUT	1	
13	6E5-24314-00-00	PIPE 4	1	
14	90465-11M10-00	.CLAMP	2	
15	6E5-24410-03-00	FUEL PUMP ASSY	1	
16	98580-05035-00	. SCREW, PAN HEAD	3	
17	92990-05600-00	. WASHER, PLATE	3	
18	6E5-24413-00-00	. BODY 2	1	
19	6E5-24471-00-00	. DIAPHRAGM	1	



CONTINUED ON NEXT FRAME >

FUEL SYSTEM

Ref No.	Part Number	Description	Qty	Remarks
20	6E5-24435-00-00	. GASKET, BODY 2	1	
21	6E5-24411-00-00	. DIAPHRAGM	1	
22	648-24424-00-00	. SEAT, SPRING	1	
23	6E5-24423-00-00	. SPRING, DIAPHRAGM	1	
24	6E5-24434-02-00	. GASKET, BODY	1	
25	6A0-24421-01-00	. VALVE, CHECK	4	
26	6A0-14325-00-00	. . .SCREW, PAN HEAD	4	
27	95380-03600-00	. . .NUT	4	
28	650-24431-A0-00	GASKET, FUEL PUMP 1	1	
29	97395-06050-00	BOLT	2	
30	92990-06600-00	. WASHER, PLATE	2	
31	6G5-24316-10-00	PIPE 6	1	
32	90465-11M10-00	. CLAMP	2	
33	6E5-24376-10-00	PIPE, JOINT 1	1	
34	6G5-24318-10-00	PIPE, OVERFLOW	1	
35	6G5-24319-10-00	PIPE, OIL	1	
36	90465-11M10-00	. CLAMP	4	
37	90446-15M07-00	HOSE (L60)	1	

