


# BRACKET 1

Ref No.	Part Number	Description	Qty	Remarks
1	6G8-43111-03-EK	BRACKET, CLAMP	1	UR METALLIC MARINE SILVER
1	6G8-43111-03-EL	BRACKET, CLAMP	1	UR HARBOR WHITE
2	6G8-43112-04-EK	BRACKET, CLAMP	1	UR METALLIC MARINE SILVER
2	6G8-43112-04-EL	BRACKET, CLAMP	1	UR HARBOR WHITE
3	616-43118-00-EK	HANDLE, TRANSOM CLIP	2	UR METALLIC MARINE SILVER
3	616-43118-00-EL	HANDLE, TRANSOM CLP	2	UR HARBOR WHITE
4	90243-04M00-00	PIN	2	
5	6E7-43116-00-00	SCREW, TRANSOM CLAMP	2	
6	648-43114-01-00	PAD, TRANSOM CLAMP	2	
7	6G8-42561-00-00	KNOB, STEERING LOCK	1	
8	6G8-43181-00-00	LEVER, TILT STOP	1	
9	682-43318-01-00	.COVER	1	
10	90109-06M25-00	BOLT	2	
11	95680-06100-00	NUT, U	2	
12	92990-06600-00	.WASHER, PLATE	2	
13	90206-10M15-00	WASHER, WAVE	1	
14	682-43339-01-00	WASHER	1	
15	6G8-43131-00-00	BOLT, CLAMP BRACKET	1	
16	90386-22M92-00	BUSH	1	
17	90386-22M93-00	BUSH	1	

CONTINUED ON NEXT FRAME >



# BRACKET 1


Ref No.	Part Number	Description	Qty	Remarks
18	90201-22428-00	WASHER, PLATE	2	
19	90185-22043-00	NUT, SELF-LOCKING	2	
20	6G5-43145-00-00	CAP, CLAMP BRACKET	1	
21	6J8-43113-01-00	PLATE, CLAMP BRACKET	1	
22	6G8-43311-14-EK	BRACKET, SWIVEL 1	1	UR METALLIC MARINE SILVER
22	6G8-43311-14-EL	BRACKET, SWIVEL 1	1	UR HARBOR WHITE
23	93700-06M03-00	NIPPLE, GREASE	1	
24	663-45119-00-00	CAP, GREASE NIPPLE	1	
25	6G8-42528-00-00	PLATE, FRICTION	1	
26	90501-18M00-00	SPRING, COMPRESSION	1	
27	90201-06M31-00	.WASHER, PLATE	1	
28	6G8-43373-00-00	SEAL, DAMPER	1	
29	97395-06025-00	BOLT	1	
30	6G8-42511-02-EK	BRACKET, STEERING	1	UR METALLIC MARINE SILVER
30	6G8-42511-02-EL	BRACKET, STEERING	1	UR HARBOR WHITE
31	6G8-42534-00-00	. PIN, DOWEL	1	
32	93605-15065-00	PIN, DOWEL	2	
33	97315-06030-00	BOLT	2	
34	92990-06600-00	.WASHER, PLATE	2	
35	6G8-42521-10-94	SHAFT, STEERING PIVOT	1	


CONTINUED ON NEXT FRAME >

# BRACKET 1

Ref No.	Part Number	Description	Qty	Remarks
36	90209-45M09-00	WASHER	1	
37	6G8-42537-00-00	BUSHING, PIVOT SHAFT	1	
38	90386-37M47-00	BUSH	1	
39	93210-37M67-00	O-RING	1	
40	90386-37M48-00	BUSH	1	
41	6G8-44517-00-94	MOUNT RUBBER	1	
42	6G8-44526-00-00	PLATE	1	
43	97395-06012-00	BOLT	2	
44	92990-06600-00	.WASHER, PLATE	2	
45	97395-08030-00	BOLT	2	
46	92990-08600-00	.WASHER, PLATE	2	
47	90116-08M28-00	BOLT, STUD	2	
48	90201-08M12-00	.WASHER, PLATE	2	
49	6G8-44522-00-00	SEAL	2	
50	90460-38M06-00	CLAMP, HOSE	2	
51	6G8-44518-00-00	BRACKET COMP.	1	
52	6G8-44533-00-00	DAMPER, UPPER MOUNT RUBBER	2	
53	95780-08300-00	NUT, FLANGE	2	
54	6G8-44521-00-00	SEAL	1	
55	6G8-44532-00-00	STOPPER, UPPER MOUNT	1	

CONTINUED ON NEXT FRAME >





# BRACKET 1

Ref No.	Part Number	Description	Qty	Remarks
56	6G8-44551-01-EK	HOUSING, LOWER MOUNT RUBBER	1	UR METALLIC MARINE SILVER
56	6G8-44551-01-EL	HOUSING, LOWER, MOUNT RUBBER	1	UR HARBOR WHITE
57	6G8-44552-02-EL	HOUSING, LOWER MOUNT RUBBER	1	UR HARBOR WHITE
57	6G8-44552-02-EK	HOUSING, LWR.MNT.MOUNT RUBBER	1	UR METALLIC MARINE SILVER
58	97395-06045-00	BOLT, HEXAGON	1	
59	92990-06600-00	.WASHER, PLATE	1	
60	97395-06095-00	BOLT	2	
61	92990-06600-00	.WASHER, PLATE	2	
62	95380-06700-00	NUT	3	
63	6G8-44557-00-00	MOUNT DAMPER, LOWER FRONT	1	
64	682-44555-00-00	MOUNT DAMPER, LOWER SIDE	2	
65	91690-30012-00	.PIN, SPRING	1	
66	90501-10071-00	..SPRING, COMPRESSION	1	
67	90101-08M88-00	BOLT	2	
68	92990-08600-00	.WASHER, PLATE	2	
69	95780-08300-00	NUT, FLANGE	2	
70	90201-08MA4-00	WASHER, PLATE	2	
71	6G8-48511-20-00	HOOK, STEERING	1	T9.9ER
72	97395-06016-00	BOLT, HEX	2	T9.9ER
73	92990-06600-00	.WASHER, PLATE	2	T9.9ER