


FUEL TANK

Ref No.	Part Number	Description	Qty	Remarks
1	6Y1-W2420-42-24	FUEL TANK ASSEMBLY	1	
2	6Y1-24244-20-00	. GRAPHIC, SIDE	1	
3	6Y1-24610-00-00	. CAP ASSEMBLY	1	
4	6Y1-24260-02-00	. FUEL METER ASSEMBLY	1	
5	6Y1-24268-00-00	. .GASKET, FUEL METER	1	
6	6Y1-24329-00-00	. .SEAL	4	
7	98586-05016-00	. .SCREW, PAN HEAD	4	
8	6Y1-24256-50-00	. GRAPHIC, FUEL TANK	1	
9	6Y1-24306-51-00	FUEL PIPE COMP. 1	1	
10	90445-11M06-00	. .HOSE (L2050)	1	
11	6Y1-24360-51-00	. PRIMER PUMP ASSY.	1	
12	90445-11M05-00	. .HOSE (L850)	1	
13	650-24351-51-00	. .BAND 1	4	
14	6G1-24305-01-00	. FUEL PIPE JOINT COMP. 2	1	
15	93210-08287-00O-RING	1	
16	6Y1-24305-02-00	. FUEL PIPE JOINT COMP. 2	1	
17	93210-08287-00O-RING	1	
18	6G1-24304-02-00	FUEL PIPE JOINT COMP. 1	1	
19	97395-06025-00	BOLT	1	
20	92990-06600-00	.WASHER, PLATE	1	

CONTINUED ON NEXT FRAME >



FUEL TANK

Ref No.	Part Number	Description	Qty	Remarks
21	90467-08004-00	CLIP	2	
22	90445-09M00-00	HOSE (L180)	1	
23	655-24560-01-00	FILTER ASSEMBLY	1	
24	6F5-24563-00-00	. ELEMENT, FILTER	1	
25	93210-37M25-00	. O-RING	1	
26	655-24521-01-00	. CUP, FILTER	1	
27	90179-08M15-00	NUT	1	
28	6E5-24312-00-00	PIPE 2	1	
29	90464-09M21-00	CLAMP	1	
30	688-24313-00-00	PIPE 3	1	
31	6J8-24311-00-00	PIPE, FUEL 1	1	
32	90467-08004-00	CLIP	6	
33	6J8-28170-00-00	TOOL, HOLDER	1	
34	6E1-42694-00-00	BAND	1	
35	97395-08016-00	BOLT	2	
36	92995-08600-00	WASHER	2	
37	90464-12M17-00	CLAMP	6	
38	ABB-FLUSH-JD-00	JET DRIVE FLUSH	1	AP