


FUEL

Ref No.	Part Number	Description	Qty	Remarks
1	6G1-24304-02-00	FUEL PIPE JOINT COMP. 1	1	
2	97395-06025-00	BOLT	1	
3	92990-06600-00	WASHER, PLATE	1	
4	90467-08004-00	CLIP	2	
5	61N-24560-00-00	FILTER ASSY	1	
6	61N-24563-00-00	. ELEMENT, FILTER	1	
7	61N-24521-00-00	..CUP, FILTER	1	
8	93210-32738-00	..O-RING	1	
9	6H4-24566-01-00	BRACKET, FILTER	1	
10	97013-06012-00	BOLT	1	
11	95380-08600-00	NUT	1	
12	6H4-24314-00-00	PIPE 4	1	
13	90467-08004-00	CLIP	2	
14	6A0-24410-05-00	FUEL PUMP ASSEMBLY	1	
15	648-24411-00-00	. DIAPHRAGM	1	
16	648-24424-00-00	..SEAT, SPRING	1	
17	648-24423-00-00	. SPRING, DIAPHRAGM	1	
18	648-24434-01-00	. GASKET, BODY	1	
19	6A0-24421-01-00	..VALVE, CHECK	2	
20	6A0-14325-00-00	...SCREW, PAN HEAD	2	

CONTINUED ON NEXT FRAME >




40mhs

B8

FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	95380-03600-00	. . .NUT	2	
22	648-24435-02-00	. GASKET, BODY 2	1	
23	663-24411-00-00	. DIAPHRAGM	1	
24	648-24413-01-00	. BODY 2	1	
25	98580-05530-00	. SCREW, PAN HEAD	3	
26	92990-05100-00	. WASHER, SPRING	3	
27	650-24431-A0-00	GASKET, FUEL PUMP 1	1	
28	97095-06040-00	BOLT	2	
29	92990-06600-00	WASHER, PLATE	2	
30	90445-09063-00	HOSE (L80)	1	
31	688-24378-00-00	PIPE, JOINT 3	2	
32	90445-09057-00	HOSE (L43)	2	
33	6H4-24313-00-00	PIPE 3	1	
34	6H4-24312-00-00	PIPE 2	1	
35	90467-08004-00	CLIP	10	
36	6H4-24311-00-00	PIPE, FUEL 1	1	
37	90464-16039-00	CLAMP	3	
38	ABB-FLUSH-JD-00	JET DRIVE FLUSH	1	



40mhs

B9