

# REPAIR KIT 1

Ref No.	Part Number	Description	Qty	Remarks
1	6H4-W0001-04-00	POWER HEAD GASKET KIT	1	
2	6H4-11181-A0-00	. GASKET, CYLINDER HEAD 1	1	
3	6H4-11193-A1-00	. GASKET, HEAD COVER 1	1	
4	90430-14115-00	. .GASKET	1	
5	6J8-12414-A0-00	. GASKET, COVER	1	
6	6H4-41112-A0-00	. .GASKET, EXHAUST INNER COVER	1	
7	6H4-41114-A0-00	. GASKET, EXHAUST COVER	1	
8	6H4-15369-A1-00	. GASKET, OIL SEAL HOUSING	1	
9	93101-16M36-00	. OIL SEAL	2	
10	93102-25M28-00	. OIL SEAL	1	
11	93210-57M09-00	. .O-RING	1	
12	6H4-13621-A1-00	. GASKET, VALVE SEAT	2	
13	6H4-14198-01-00	. .GASKET	3	
14	6H3-14457-01-00	. SEAL	3	
15	6H4-14984-00-00	. .GASKET, FLOAT CHAMBER	3	
16	93210-32738-00	. .O-RING	1	
17	650-24431-A0-00	. GASKET, FUEL PUMP 1	1	
18	6H4-45113-A0-00	. GASKET, UPPER CASING	1	
19	6H4-W0093-03-00	CARBURETOR REPAIR KIT	1	
20	6H4-14198-01-00	. .GASKET	3	

CONTINUED ON NEXT FRAME >



