





CONTROL

Ref No.	Part Number	Description	Qty	Remarks
1	6E5-48531-00-00	BRACKET, REMOTE CONTROL 1	1	
2	6E5-48538-00-00	CLAMP, CABLE	2	
3	91690-30012-00	.PIN, SPRING	2	
4	97395-08020-00	BOLT, HEXAGON	1	
5	92990-08100-00	.WASHER, SPRING	1	
6	6K7-41632-00-94	LEVER, MAGNETO CONTROL (6K7-41632-01-94)	1	
7	663-85518-00-00	JOINT, BALL	1	
8	6E5-48344-00-00	CABLE END, REMOTE CONTROL	1	
9	92990-06200-00	WASHER, PLAIN	1	
10	90185-06M07-00	NUT, SELF-LOCKING	1	
11	97313-08045-00	BOLT, HEXAGON	1	
12	90201-08M61-00	WASHER, PLATE	1	
13	90206-12M00-00	WASHER, WAVE	1	
14	90386-12069-00	BUSH	2	
15	90387-08M16-00	COLLAR	1	
16	6K7-41211-00-00	LINK, ACCEL.	1	
17	95380-05600-00	.NUT	1	
18	6H1-41237-00-00	JOINT, LINK	1	
19	6K7-41213-00-00	CAM, ACCEL.	1	
20	90387-06M29-00	COLLAR	1	


CONTINUED ON NEXT FRAME >



CONTROL

Ref No.	Part Number	Description	Qty	Remarks
21	90206-10M04-00	.WASHER, WAVE	1	
22	97095-06025-00	.BOLT	1	
23	6E5-44117-00-94	BRACKET	1	
24	97595-06520-00	BOLT, WITH WASHER	2	
25	6E5-44121-00-00	LEVER, SHIFT ROD	1	
26	6E5-44122-00-00	BUSHING, SHIFT ROD LEVER	1	
27	90202-08M20-00	WASHER, PLATE	2	
28	90468-18008-00	.CLIP	2	
29	6E5-48344-00-00	CABLE END, REMOTE CONTROL	1	
30	92990-06200-00	WASHER, PLAIN	1	
31	90185-06M07-00	NUT, SELF-LOCKING	1	
32	90386-06M12-00	BUSH	1	
33	6E5-44118-01-94	BRACKET	1	
34	97313-08030-00	BOLT	2	
35	92990-08600-00	.WASHER, PLATE	2	
36	93501-04M02-00	BALL	1	
37	90501-12082-00	SPRING, COMPRESSION	1	
38	648-42715-00-00	BUSHING	1	
39	93700-06M03-00	NIPPLE, GREASE	1	
40	6E5-44120-03-00	HANDLE GEAR SHIFT ASSY	1	LONG

CONTINUED ON NEXT FRAME >



225tlrt

CONTROL

Ref No.	Part Number	Description	Qty	Remarks
41	93210-09350-00	O-RING	1	
42	90386-16M66-00	BUSH	1	
43	90202-16061-00	WASHER, PLATE	2	
44	99009-16400-00	.CIRCLIP	1	

C12