





FUEL

Ref No.	Part Number	Description	Qty	Remarks
1	6R3-24313-10-00	PIPE 3 (L:1620)	1	
2	6R3-24377-00-00	PIPE, JOINT 2	1	
3	90465-11M10-00	.CLAMP	3	
4	6R3-24560-00-00	FILTER ASSY	1	
5	6R3-24563-00-00	.ELEMENT, FILTER	1	
6	61N-24521-00-00	.CUP, FILTER	1	
7	93210-32738-00	.O-RING	1	
8	648-24566-01-00	BRACKET, FILTER	1	
9	97313-06014-00	BOLT, HEXAGON	1	
10	92995-06100-00	WASHER, SPRING	1	
11	95380-08600-00	NUT	1	
12	90445-13M31-00	HOSE (L85)	1	
13	6R5-24408-00-00	FUEL FEED ASSY	1	
14	6R5-24314-00-00	PIPE 4	1	
15	90465-11M10-00	.CLAMP	3	
16	6G5-24376-00-00	PIPE, JOINT 1	1	
17	6K7-24315-00-00	PIPE 5	1	
18	6E5-24315-00-00	PIPE 5	1	
19	90465-11M10-00	.CLAMP	5	
20	6E5-24410-03-00	FUEL PUMP ASSY	2	


CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	98580-05035-00	. SCREW, PAN HEAD	3	
22	92990-05600-00	. WASHER, PLATE	3	
23	6E5-24413-00-00	. BODY 2	1	
24	6E5-24471-00-00	. DIAPHRAGM	1	
25	6E5-24435-00-00	. GASKET, BODY 2	1	
26	6E5-24411-00-00	. DIAPHRAGM	1	
27	648-24424-00-00	.SEAT, SPRING	1	
28	6E5-24423-00-00	. SPRING, DIAPHRAGM	1	
29	6E5-24434-02-00	. GASKET, BODY	1	
30	6A0-24421-01-00	. VALVE, CHECK	4	
31	6A0-14325-00-00	...SCREW, PAN HEAD	4	
32	95380-03600-00	...NUT	4	
33	650-24431-A0-00	GASKET, FUEL PUMP 1	2	
34	97395-06050-00	BOLT	4	
35	92990-06600-00	.WASHER, PLATE	4	
36	6G5-24316-10-00	PIPE 6	2	
37	90465-11M10-00	.CLAMP	4	
38	6E5-24378-00-00	PIPE, JOINT 3	3	
39	90445-13M03-00	HOSE (L50)	1	
40	90445-13M02-00	HOSE (L40)	1	


CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
41	6K7-24317-00-00	PIPE 7	1	
42	6K7-24318-00-00	PIPE, OVERFLOW	1	
43	6K7-24319-00-00	PIPE, OIL	1	
44	90465-11M10-00	.CLAMP	12	
45	6R5-13921-01-00	PRIME STARTER	1	
46	6R5-24479-00-00	. O-RING, SEPARATER 1	2	
47	6R5-24435-00-00	. GASKET, BODY 2	1	
48	6R5-24434-00-00	. GASKET, BODY	1	
49	97980-05125-00	. SCREW, WITH WASHER	3	
50	6R5-24489-00-00	. O-RING, SEPARATER 2	1	
51	6E5-14997-00-00	. O-RING	1	
52	97980-04125-00	. .SCREW, WITH WASHER	2	
53	6R5-24411-00-00	. DIAPHRAGM	1	
54	650-24431-A0-00	GASKET, FUEL PUMP 1	1	
55	97095-06035-00	BOLT	2	
56	92990-06600-00	.WASHER, PLATE	2	
57	97395-06055-00	BOLT (97313-06055-00)	2	
58	92990-06600-00	.WASHER, PLATE	2	
59	6R5-24316-00-00	PIPE 6	1	
60	90445-07M24-00	HOSE (L240)	1	

CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
61	90445-07M46-00	HOSE (L360)	1	
62	90445-07M10-00	HOSE (L510)	1	
63	90468-07M02-00	CLIP	6	
64	90464-07M05-00	CLAMP	1	
65	90464-07M20-00	CLAMP	1	