


ELECTRICAL 2

Ref No.	Part Number	Description	Qty	Remarks
1	6E5-85570-11-00	IGNITION COIL ASSEMBLY	4	
2	97095-06030-00	BOLT	8	
3	92990-06600-00	.WASHER, PLATE	8	
4	90465-08028-00	CLAMP	4	
5	663-82370-01-00	PLUG CAP ASSY	4	
6	61A-81941-00-00	STARTER RELAY ASSY	1	
7	689-81952-10-00	HOLDER, RELAY	1	
8	6E5-81950-00-00	RELAY ASSY	1	
9	6E5-8195A-00-00	RELAY ASSY	1	
10	6G5-87149-10-00	CONNECTOR	1	
11	6E5-82116-00-00	WIRE, MINUS LEAD	1	
12	6E5-81948-22-00	BRACKET	1	
13	97095-06016-00	BOLT	2	
14	92990-06600-00	.WASHER, PLATE	2	
15	6N7-83557-00-00	TUBE (I.DIA:22MM)	1	
16	90465-13M36-00	CLAMP	1	
17	6E5-86110-02-00	SOLENOID	1	
18	6E5-86116-01-00	. WIRE, PULL	1	
19	91609-30010-00	. PIN, SPRING	1	
20	97095-06016-00	BOLT	2	

CONTINUED ON NEXT FRAME >



ELECTRICAL 2

Ref No.	Part Number	Description	Qty	Remarks
21	92990-06600-00	.WASHER, PLATE	2	
22	93210-03261-00	O-RING	1	
23	688-82560-10-00	THERMO SWITCH ASSY	2	
24	6E5-82590-03-00	WIRE HARNESS ASSEMBLY	1	
25	682-82151-00-00	. FUSE (12V-20A)	1	
26	6E5-82105-12-00	BATTERY CABLE	1	
27	6E5-82117-00-00	WIRE, LEAD	1	
28	6E5-82519-00-00	WIRE, EARTH LEAD	1	
29	6E5-82531-00-00	WIRE, LEAD	1	
30	97095-06012-00	.BOLT	3	
31	92990-06600-00	.WASHER, PLATE	3	
32	90465-08M08-00	CLAMP	2	
33	90446-10M01-00	HOSE (L60)	1	
34	90465-12M25-00	CLAMP	1	
35	90465-13M36-00	CLAMP	1	
36	6G5-82152-00-00	HOLDER, FUSE	1	
37	6G5-82119-20-00	COVER, LEAD WIRE	2	

c115tru

D10