


STARTER

Ref No.	Part Number	Description	Qty	Remarks
1	689-15710-04-00	STARTER ASSEMBLY	1	
2	676-15711-01-94	. CASE, STARTER	1	
3	91690-40020-00	. PIN, SPRING	2	
4	689-15758-01-94	. GUIDE, ROPE	1	
5	97095-06016-00	. BOLT	2	
6	92990-06600-00	. WASHER, PLATE	2	
7	689-15762-01-00	. SEAL, RUBBER 2	1	
8	689-15789-00-00	. DAMPER	1	
9	689-15755-01-00	. HANDLE, STARTER	1	
10	90580-50M01-00	. ROPE, STARTER	1	
11	676-15714-00-94	. DRUM, SHEAVE	1	
12	91690-40020-00	. PIN, SPRING	1	
13	90510-09M00-00	. SPRING, SPIRAL	1	
14	676-15717-00-00	. SHAFT, STARTER	1	
15	90201-08309-00	. WASHER, PLATE	1	
16	97013-08025-00	. BOLT	1	
17	95333-08600-00	. NUT	1	
18	676-15799-01-00	. CLIP	1	
19	90386-35M01-00	. BUSH	1	
20	676-15741-03-00	. PAWL, DRIVE	1	


CONTINUED ON NEXT FRAME >



STARTER

Ref No.	Part Number	Description	Qty	Remarks
21	93430-06M02-00	.CIRCLIP	1	
22	676-15705-00-00	.SPRING, DRIVE PAWL	1	
23	676-15773-00-00	.STAY 3	6	
24	6F5-15779-02-00	.COVER	1	
25	97095-08035-00	BOLT	1	
26	92990-08600-00	.WASHER, PLATE	1	
27	99510-12016-00	PIN, DOWEL	1	
28	97095-06030-00	BOLT	2	
29	92990-06600-00	.WASHER, PLATE	2	
30	95380-06600-00	NUT, HEXAGON	2	UR C25MH
30	95380-06600-00	NUT, HEXAGON	1	UR C25ER/EH
31	6H7-15771-01-94	STAY 1	1	
32	656-15772-00-94	STAY 2	1	UR C25MH
32	695-15772-40-94	STAY 2	1	UR C25ER/EH
33	97095-06025-00	.BOLT	2	UR C25ER/EH
33	97095-06025-00	.BOLT	4	UR C25MH
34	92990-06600-00	.WASHER, PLATE	4	UR C25MH
34	92990-06600-00	.WASHER, PLATE	2	UR C25ER/EH
35	97013-06045-00	BOLT	1	
36	92990-06600-00	.WASHER, PLATE	1	

CONTINUED ON NEXT FRAME >



STARTER

Ref No.	Part Number	Description	Qty	Remarks
37	656-15770-00-00	CABLE COMP., STARTER STOP	1	
38	90123-06M00-00	. BOLT	1	
39	95380-06600-00	. NUT, HEXAGON	2	
40	656-15748-00-00	PLUNGER, STARTER STOP	1	
41	90501-10227-00	SPRING, COMPRESSION	1	
42	656-15774-41-00	STAY 4 (FOR NEUTRAL SWITCH)	1	UR C25EH
42	656-15774-00-00	STAY 4	1	UR C25ER/MH
43	97095-06010-00	BOLT	1	
44	656-15749-00-00	LINK, STARTER STOP	1	
45	97095-06020-00	BOLT	1	
46	92990-06600-00	.WASHER, PLATE	1	
47	90206-08010-00	WASHER, WAVE	1	
48	90387-06568-00	COLLAR	1	
49	90206-05005-00	WASHER, WAVE	1	C25ER
50	92990-05600-00	WASHER, PLATE	1	C25ER
51	91490-16010-00	PIN. COTTER	1	C25ER
52	97095-06030-00	BOLT	2	C25ER/EH
53	92990-06600-00	.WASHER, PLATE	2	C25ER/EH
54	689-81332-01-00	PLATE, TIMING	1	