

# GENERATOR

| Ref No. | Part Number     | Description            | Qty | Remarks |
|---------|-----------------|------------------------|-----|---------|
| 1       | 6J8-85550-F0-00 | ROTOR ASSEMBLY         | 1   |         |
| 2       | 6H4-85510-F0-00 | STATOR ASSEMBLY        | 1   |         |
| 3       | 6H4-85520-00-00 | . COIL, CHARGE         | 1   |         |
| 4       | 98580-06020-00  | . SCREW, PAN HEAD      | 2   |         |
| 5       | 92995-06100-00  | . WASHER, SPRING       | 2   |         |
| 6       | 6H4-85548-00-00 | . .HOLDER              | 1   |         |
| 7       | 98507-05008-00  | . SCREW, PAN HEAD      | 1   |         |
| 8       | 92990-05100-00  | . WASHER, SPRING       | 1   |         |
| 9       | 6H4-85533-A0-00 | COIL, LIGHTING         | 1   |         |
| 10      | 663-85518-00-00 | .JOINT, BALL           | 1   |         |
| 11      | 90280-16053-00  | KEY, WOODRUFF          | 1   |         |
| 12      | 90179-16M05-00  | NUT                    | 1   |         |
| 13      | 90201-16M44-00  | WASHER, PLATE          | 1   |         |
| 14      | 6H4-41611-10-00 | RETAINER, MAGNETO BASE | 1   |         |
| 15      | 6J8-41615-00-00 | STOPPER, MAGNETO BASE  | 2   |         |
| 16      | 6J8-41618-00-00 | WASHER, MAGNETO        | 1   |         |
| 17      | 98580-06012-00  | SCREW, PAN HEAD        | 2   |         |
| 18      | 6J8-85548-00-00 | HOLDER                 | 1   |         |
| 19      | 90101-06M00-00  | BOLT                   | 2   |         |
| 20      | 90387-06M76-00  | COLLAR                 | 2   |         |

CONTINUED ON NEXT FRAME >



