


FUEL


Ref No.	Part Number	Description	Qty	Remarks
1	6E5-24304-10-00	FUEL PIPE JOINT COMP 1	1	
2	97095-06028-00	BOLT	1	
3	61U-24313-00-00	PIPE 3	1	
4	90465-11M10-00	CLAMP	2	
5	61A-24560-02-00	FILTER ASSEMBLY	1	
6	61A-24521-00-00	. CUP, FILTER	1	
7	61A-24531-00-00	. NUT	1	
8	61A-24564-00-00	. O-RING	1	
9	61A-24577-01-00	. SPRING	1	
10	61A-24563-00-00	. ELEMENT, FILTER	1	
11	61A-24469-00-00	. FLOAT, WATER LEVEL	1	
12	61U-24566-00-00	BRACKET, FILTER	1	
13	97595-06416-00	BOLT, WITH WASHER	2	
14	97595-06414-00	BOLT, WITH WASHER	2	
15	61U-24314-00-00	PIPE 4	1	
16	90465-11M10-00	CLAMP	1	
17	90465-11M10-00	CLAMP	1	
18	6E5-24410-03-00	FUEL PUMP ASSY	1	
19	98580-05035-00	. SCREW, PAN HEAD	3	
20	92990-05600-00	. WASHER, PLATE	3	

CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	6E5-24413-00-00	. BODY 2	1	
22	6E5-24471-00-00	. DIAPHRAGM	1	
23	6E5-24435-00-00	. GASKET, BODY 2	1	
24	6E5-24411-00-00	. DIAPHRAGM	1	
25	648-24424-00-00	. .SEAT, SPRING	1	
26	6E5-24423-00-00	. .SPRING, DIAPHRAGM	1	
27	6E5-24434-02-00	. GASKET, BODY	1	
28	6A0-24421-01-00	. .VALVE, CHECK	4	
29	6A0-14325-00-00	. .SCREW, PAN HEAD	4	
30	95380-03600-00	. .NUT	4	
31	6E5-24412-02-00	. BODY 1	1	
32	650-24431-A0-00	GASKET, FUEL PUMP 1	1	
33	97095-06050-00	BOLT	2	
34	92990-06600-00	WASHER, PLATE	2	
35	6G5-24316-10-00	PIPE 6	1	
36	90465-11M10-00	CLAMP	1	
37	90465-11M10-00	CLAMP	1	
38	6E5-24376-10-00	PIPE, JOINT 1	1	
39	6G5-24318-10-00	PIPE, OVERFLOW	1	
40	6G5-24319-10-00	PIPE, OIL	1	



CONTINUED ON NEXT FRAME >

