




GENERATOR

Ref No.	Part Number	Description	Qty	Remarks
1	6H2-85550-00-00	ROTOR ASSY	1	(70TR)
2	6H2-85520-01-00	COIL, CHARGE	1	(70TR)
3	6H2-85533-01-00	COIL, LIGHTING	1	(70TR)
4	6H2-85580-01-00	COIL, PULSER	1	(70TR)
5	6H2-85895-01-00	CRANK POSITION SENDER	1	(70TR)
6	97095-05012-00	.BOLT	4	(70TR)
7	97095-06035-00	BOLT	4	(70TR)
8	92995-06600-00	WASHER	4	(70TR)
9	97095-06025-00	.BOLT	3	(70TR)
10	92995-06600-00	WASHER	3	(70TR)
11	90280-05015-00	KEY, WOODRUFF	1	(70TR)
12	90170-20137-00	NUT	1	(70TR)
13	90201-21M18-00	WASHER, PLATE	1	(70TR)
14	6E5-81332-00-00	PLATE, TIMING	1	(70TR)
15	97885-06010-00	SCREW, PAN HEAD	1	(70TR)
16	92995-06600-00	WASHER	1	(70TR)
17	6H3-81337-01-00	COVER, FLYWHEEL	1	(70TR)
18	90159-06M23-00	SCREW, WITH WASHER	3	(70TR)