


REPAIR KIT 1




Ref No.	Part Number	Description	Qty	Remarks
1	697-W0001-02-00	POWER HEAD GASKET KIT	1	
2	663-14483-A0-00	. GASKET	1	
3	663-14198-A0-00	. GASKET	2	
4	663-13621-A0-00	. GASKET, VALVE SEAT	2	
5	663-13622-A0-00	. GASKET, VALVE SEAT	2	
6	93210-64272-00	. O-RING	2	
7	697-11181-A1-00	. GASKET, CYLINDER HEAD 1	1	
8	663-11193-A0-00	. GASKET, HEAD COVER 1	1	
9	663-12414-A0-00	. GASKET, COVER	1	
10	663-41114-A0-00	. GASKET, EXHAUST OUTER COVER	1	
11	93210-42159-00	. O-RING	1	
12	93102-32M07-00	. OIL SEAL	1	
13	93102-28135-00	. OIL SEAL	1	
14	93104-18049-00	. OIL SEAL	1	
15	93210-62269-00	. O-RING	1	
16	696-45113-A0-00	. GASKET, UPPER CASING	1	
17	93210-32738-00	. O-RING	1	
18	650-24431-A0-00	. GASKET, FUEL PUMP 1	1	
19	696-W0093-02-00	CARBURETOR REPAIR KIT	1	
20	663-14483-A0-00	. GASKET	1	

CONTINUED ON NEXT FRAME >



6970700-4220

REPAIR KIT 1



Ref No.	Part Number	Description	Qty	Remarks
21	663-14198-A0-00	. GASKET	2	
22	679-14557-00-00	. WASHER	2	
23	663-14923-00-00	. SCREW, PILOT	2	
24	696-14590-00-00	. NEEDLE VALVE ASSY	2	
25	93210-07229-00	. O-RING	2	
26	810-14186-00-00	. PIN, FLOAT	2	
27	6F0-14985-00-00	. FLOAT	2	
28	663-14548-00-00	. PIN, FLOAT ARM	2	
29	93210-64272-00	. O-RING	2	
30	97980-04112-00	. SCREW, WITH WASHER	2	
31	93210-04230-00	. O-RING	2	



6970700-4220