


FUEL

Ref No.	Part Number	Description	Qty	Remarks
1	90480-06M19-00	GROMMET	1	
2	90445-13M23-00	HOSE (L1350)	1	
3	67F-24377-00-00	PIPE, JOINT 2	1	
4	90465-11M10-00	.CLAMP	2	
5	90445-11M49-00	HOSE (L700)	1	
6	67F-24251-01-00	STRAINER 1	1	
7	90445-11M50-00	HOSE (L205)	1	
8	688-24378-00-00	PIPE, JOINT 3	1	
9	90445-11M51-00	HOSE (L45)	1	
10	90445-117F0-00	HOSE (L120)	1	
11	90445-16M07-00	HOSE (L80)	1	
12	90465-11M10-00	.CLAMP	3	
13	90467-10M04-00	CLIP	4	
14	6E5-82588-00-00	PLATE	2	
15	90109-06M81-00	.BOLT	2	
16	67F-24410-00-00	FUEL PUMP ASSY	2	
17	67F-24413-00-00	. BODY 2	1	
18	6A0-24421-01-00	..VALVE, CHECK	2	
19	67F-24411-00-00	. DIAPHRAGM	1	
20	62Y-24423-00-00	..SPRING, DIAPHRAGM	1	

CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	67F-13131-00-00	. PLUNGER	1	
22	67F-24454-00-00	. SPRING	1	
23	62Y-24444-00-00	. .SCREW	4	
24	62Y-24471-00-00	. .DIAPHRAGM	1	
25	6A0-24453-00-00	. SCREW	2	
26	62Y-24452-00-00	. .PACKING	1	
27	95380-05600-00	. .NUT	4	
28	67F-24374-00-00	. PIN	1	
29	93210-30682-00	.O-RING	2	
30	90119-06M83-00	BOLT, WITH WASHER	4	
31	67F-24575-00-00	LEVER, FUEL CHANGE	2	
32	67F-24495-00-00	SHAFT	1	
33	91609-25014-00	PIN, SPRING	2	
34	90201-08M12-00	.WASHER, PLATE	2	
35	67F-24491-00-00	BRACKET, FUEL PUMP	1	
36	90119-07235-00	.BOLT/WASHER-CAM CAPS	2	
37	91809-08006-00	.PIN, DOWEL	2	