



OIL PAN

Ref No.	Part Number	Description	Qty	Remarks
1	66M-41137-00-5B	GUIDE, EXHAUST	1	(PR)
2	93101-12M63-00	.OIL SEAL	1	(PR)
3	93606-12019-00	PIN, DOWEL	2	(PR)
4	66M-11355-00-00	SEAL, CYLINDER 1	1	(PR)
5	97095-06020-00	BOLT	2	(PR)
6	92995-06600-00	WASHER	2	(PR)
7	66M-41131-01-94	MANIFOLD, EXT. 1	1	(PR)
8	66M-41133-00-00	.GASKET, EXHAUST MANIFOLD 1	1	(PR)
9	97095-06016-00	BOLT	2	(PR)
10	92995-06600-00	WASHER	2	(PR)
11	66M-41138-00-00	.SEAL, EXT. 1	1	(PR)
12	66M-13421-00-00	STRAINER 2	1	(PR)
13	66M-13417-00-00	COVER, STRAINER	1	(PR)
14	66M-13416-00-00	PIPE, OIL 1	1	(PR)
15	66M-24351-00-00	BAND 1	2	(PR)
16	6G8-11575-00-00	RELIEF VALVE ASSY	1	(PR)
17	90340-14M06-00	PLUG, STRAIGHT SCREW	1	(PR)
18	90430-14M09-00	.GASKET	1	(PR)
19	66M-15316-00-00	DAMPER, ENGINE MOUNT 1	1	(PR)
20	66M-15362-00-00	PLUG, OIL LEVEL	1	(PR)