



66M0010-1050

VALVE

Ref No.	Part Number	Description	Qty	Remarks
1	66M-12111-00-00	VALVE, INTAKE	2	(PR)
2	66M-12121-00-00	VALVE, EXHAUST	2	(PR)
3	66M-12116-00-00	SEAT, VALVE SPRING	4	(PR)
4	66M-12113-00-00	SPRING, VALVE INNER	4	(PR)
5	30X-12117-00-00	RETAINER, VALVE SPRING	4	(PR)
6	30X-12118-00-00	LOCK, VALVE SPRING RETAINER	8	(PR)
7	51Y-12119-00-00	SEAL, VALVE STEM	4	(PR)
8	66M-12146-00-00	SHAFT, ROCKER	2	(PR)
9	90387-13M56-00	COLLAR	3	(PR)
10	90387-13001-00	COLLAR	1	(PR)
11	90387-13002-00	COLLAR	1	(PR)
12	90501-12M40-00	SPRING, COMPRESSION	3	(PR)
13	90501-12M41-00	SPRING, COMPRESSION	1	(PR)
14	66M-12151-00-00	ARM, VALVE ROCKER	4	(PR)
15	62Y-12159-00-00	SCREW, VALVE ADJUSTING	4	(PR)
16	62Y-12158-00-00	NUT, LOCK	4	(PR)