


6L20100-4260

REPAIR KIT 1

Ref No.	Part Number	Description	Qty	Remarks
1	6L2-W0001-03-00	POWER HEAD GASKET KIT	1	(25MH)
2	93102-25142-00	..OIL SEAL	1	(25MH)
3	93101-13M37-00	..OIL SEAL	1	(25MH)
4	93210-56M80-00	..O-RING	1	(25MH)
5	6L2-11181-A2-00	..GASKET, CYLINDER HEAD 1	1	(25MH)
6	6L2-11193-A1-00	..GASKET, HEAD COVER 1	1	(25MH)
7	6J8-12414-A0-00	..GASKET, COVER	1	(25MH)
8	6L2-41114-A1-00	..GASKET, EXHAUST OUTER COVER	1	(25MH)
9	6L2-41112-A1-00	..GASKET, EXHAUST INNER COVER	1	(25MH)
10	93102-26M27-00	..OIL SEAL	1	(25MH)
11	93210-42159-00	..O-RING	1	(25MH)
12	6L2-13621-00-00	..GASKET, VALVE SEAT	1	(25MH)
13	6L2-14384-00-00	..GASKET, FLOAT CHAMBER	2	(25MH)
14	6L2-14198-00-00	..GASKET	2	(25MH)
15	93210-32738-00	..O-RING	1	(25MH)
16	6L2-45113-A1-00	..GASKET, UPPER CASING	1	(25MH)
17	6L2-41133-A1-00	..GASKET, EXHAUST MANIFOLD 1	1	(25MH)
18	6L2-W0093-00-00	CARBURETOR REPAIR KIT	1	(25MH)
19	6L2-14198-00-00	..GASKET	2	(25MH)
20	6L2-14384-00-00	..GASKET, FLOAT CHAMBER	2	(25MH)

CONTINUED ON NEXT FRAME >



6L20100-4260

REPAIR KIT 1

Ref No.	Part Number	Description	Qty	Remarks
21	6L2-14385-00-00	..FLOAT	2	(25MH)
22	6E5-14386-01-00	..PIN, FLOAT	2	(25MH)
23	6L2-14392-00-00	..VALVE, NEEDLE	2	(25MH)
24	6L2-14399-00-00	..GASKET	2	(25MH)
25	97980-04112-00	..SCREW, WITH WASHER	2	(25MH)
26	6L2-14398-00-00	..GASKET	2	(25MH)