


6L51100-8010
3msha

COWLING FUEL

Ref No.	Part Number	Description	Qty	Remarks
1	6L5-42610-13-4D	TOP COWLING ASSY	1	(3MH)
2	6L5-W0070-13-00	..GRAPHIC SET	1	(3MH)
3	6L5-42678-12-00	..GRAPHIC, REAR	1	(3MH)
4	6L5-42711-11-00	COWLING, BOTTOM	1	(3MH)
5	6L5-42712-12-00	COWLING, BOTTOM	1	(3MH)
6	6L5-42774-00-00	STAY, APRON 1	1	(3MH)
7	6L5-42775-00-00	STAY, APRON 2	1	(3MH)
8	97880-05010-00	SCREW, PAN HEAD	2	(3MH)
9	97095-06016-00	BOLT	4	(3MH)
10	92995-06600-00	WASHER	4	(3MH)
11	6L5-42647-00-00	HOLDER, CLAMP BAND	2	(3MH)
12	6L5-42823-00-00	PLATE, STOP	2	(3MH)
13	90167-03M02-00	SCREW, TAPPING	2	(3MH)
14	6L5-44191-00-00	INDICATOR, SHIFT	1	(3MH)
15	6L5-24591-00-00	EMBLEM, FUEL COCK	1	(3MH)
16	6L5-42662-00-00	DAMPER	1	(3MH)
17	6L5-42663-00-00	DAMPER	1	(3MH)
18	6L5-24111-02-00	TANK, FUEL	1	(3MH)
19	6L5-24610-00-00	CAP ASSY	1	(3MH)
20	6A0-82317-00-00	DAMPER, IGNITION COIL	3	(3MH)

CONTINUED ON NEXT FRAME >



6L51100-8010
3msha

COWLING FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	624-42542-00-00	PIPE	3	(3MH)
22	90119-06M65-00	BOLT, WITH WASHER	2	(3MH)
23	6L5-24641-00-00	GASKET, CAP 1	1	(3MH)
24	6L5-24500-60-00	FUEL COCK ASSY 1	1	(3MH)
25	90159-06M10-00	SCREW, WITH WASHER	1	(3MH)
26	6L5-44196-00-00	INDICATOR 3	1	(3MH)
27	6L5-44197-00-00	INDICATOR 4	1	(3MH)
28	6L5-24251-00-00	STRAINER 1	1	(3MH)
29	6L5-24311-00-00	PIPE, FUEL 1	1	(3MH)
30	90467-08004-00	CLIP	2	(3MH)
31	6L5-24312-00-00	PIPE 2	1	(3MH)
32	90465-13M11-00	CLAMP	2	(3MH)