




GENERATOR

Ref No.	Part Number	Description	Qty	Remarks
1	6L5-85550-M0-00	ROTOR ASSY	1	(3MH)
2	6L5-85560-M1-00	BASE ASSY	1	(3MH)
3	6E0-85520-70-00	. COIL, CHARGE	1	(3MH)
4	6L5-85595-M0-00	. COIL, PULSER	1	(3MH)
5	6L5-85592-M0-00	. PULSER COIL ASSY	1	(3MH)
6	6E0-81336-70-00	. GROMMET	1	(3MH)
7	6E0-81328-70-00	. CLAMP	1	(3MH)
8	90159-05038-00	. SCREW, WITH WASHER	2	(3MH)
9	90159-05037-00	. SCREW, WITH WASHER	2	(3MH)
10	90159-04036-00	. SCREW, WITH WASHER	2	(3MH)
11	90159-04035-00	. SCREW, WITH WASHER	1	(3MH)
12	6L5-15771-01-94	. STAY 1	1	(3MH)
13	90446-10M01-00	. HOSE (L60)	1	(3MH)
14	97803-05008-00	. SCREW, PAN HEAD	1	(3MH)
15	90465-10M34-00	. CLAMP	1	(3MH)
16	95895-06016-00	. BOLT, FLANGE	2	(3MH)
17	90280-04M06-00	KEY, WOODRUFF	1	(3MH)
18	90170-10113-00	NUT	1	(3MH)
19	90201-10126-00	WASHER, PLATE	1	(3MH)



6L51100-4050
3msha