




STARTER

Ref No.	Part Number	Description	Qty	Remarks
1	6L5-15710-00-00	STARTER ASSY	1	(3MH)
2	6L5-15711-00-00	. .CASE, STARTER	1	(3MH)
3	90387-06M70-00	. . COLLAR	1	(3MH)
4	6L5-15714-00-00	. .DRUM, SHEAVE	1	(3MH)
5	6L5-15741-00-00	. .PAWL, DRIVE	1	(3MH)
6	6L5-15713-00-00	. .SPRING, STARTER	1	(3MH)
7	6L5-15716-00-00	. .PLATE, DRIVE	1	(3MH)
8	6A1-15705-00-00	. .SPRING, DRIVE PAWL	1	(3MH)
9	97313-06012-00	. .BOLT	1	(3MH)
10	6A1-15767-00-00	. .SPRING	1	(3MH)
11	90580-50M01-00	. STARTER ROPE	1	(3MH)
12	95895-06020-00	BOLT, FLANGE	2	(3MH)
13	95895-06035-00	BOLT, FLANGE	1	(3MH)
14	6L5-15758-00-98	GUIDE, ROPE	1	(3MH)
15	95895-06016-00	.BOLT, FLANGE	2	(3MH)
16	6L5-15761-00-00	SEAL, RUBBER 1	1	(3MH)
17	6L5-42677-10-00	GRAPHIC, FRONT	1	(3MH)
18	6L5-15755-00-00	HANDLE, STARTER	1	(3MH)
19	6L5-15779-00-00	COVER	1	(3MH)
20	6L5-15789-00-00	DAMPER	1	(3MH)


CONTINUED ON NEXT FRAME >



6L51110-2040

3msha

B1



STARTER

Ref No.	Part Number		Description	Qty	Remarks
21	6H8-42791-00-00	MARK 1		1	(3MH)
22	6A1-83625-41-00	MARK 5		1	(3MH)