


# OPTIONAL PARTS

Ref No.	Part Number	Description	Qty	Remarks
1	63D-82575-00-00	ENGINE STOP SWITCH ASSY	1	AP
2	682-82556-00-00	. .LANYARD, STOP SWITCH	1	
3	689-8257Y-00-00	. .CAP	1	
4	6H5-82510-01-00	MAIN SWITCH ASSY	1	AP
5	676-82577-00-00	. .CAP, KEY	1	
6	63D-8252F-01-4D	COVER, MAIN SWITCH 2	1	AP
7	63D-8252E-01-4D	COVER, MAIN SWITCH	1	AP
8	97885-06025-00	SCREW, PAN HEAD	1	AP
9	92995-06100-00	WASHER, SPRING	1	AP
10	97095-06025-00	BOLT	1	AP
11	92995-06100-00	WASHER, SPRING	1	AP
12	97095-06020-00	BOLT	1	AP
13	92995-06100-00	WASHER, SPRING	1	AP
14	6H2-82586-01-00	EXTENSION, WIRE HARNESS	1	AP
15	6H5-83553-11-00	WIRE, LEAD	1	AP
16	90465-13M36-00	CLAMP	1	AP
17	97885-06012-00	SCREW, PAN HEAD	1	AP
18	63D-82563-00-00	TRIM & TILT SWITCH	1	AP
19	97885-06016-00	SCREW, PAN HEAD	2	AP
20	92995-06600-00	WASHER	2	AP

CONTINUED ON NEXT FRAME >



## OPTIONAL PARTS

Ref No.	Part Number	Description	Qty	Remarks
21	63D-83728-00-00	CONNECTOR ASSY	1	AP
22	90465-13M24-00	CLAMP	1	AP
23	6F5-82540-00-00	NEUTRAL SWITCH ASSEMBLY	1	AP
24	6J8-82554-00-00	STAY, NEUTRAL SWITCH	1	AP
25	90109-06M86-00	BOLT	2	AP

67C0100-1351  
f40mh\_tr\_er\_f30mh\_tra