


FUEL INJECTION NOZZLE

Ref No.	Part Number	Description	Qty	Remarks
1	68V-13160-00-00	DELIVERY PIPE ASSY 1	1	
2	68V-8A360-00-00	INJECTOR UNIT	4	
3	68V-13766-00-00	. RUBBER, INJECTOR	1	
4	68V-14225-00-00	.CAP	1	
5	68V-13435-00-00	NIPPLE	1	
6	68V-14397-00-00	.O-RING	1	
7	68V-81147-00-00	SCREW 3	2	
8	68V-13906-00-00	REGULATOR, PRESSURE	1	
9	68V-14565-00-00	.SCREW	2	
10	68V-14356-00-00	WASHER, SPRING	2	
11	68V-14264-00-00	COLLAR	2	
12	68V-21841-00-00	COOLER	1	
13	68V-13971-00-00	PIPE, FUEL 1	1	
14	68V-13972-00-00	PIPE, FUEL 2	1	
15	68V-24519-00-00	CLIP	3	
16	68V-2411M-00-00	CLIP	3	
17	68V-14777-00-00	BOLT	2	
18	68V-14428-00-00	BOLT	2	
19	68V-14475-00-00	WASHER	2	
20	68V-14357-00-00	WASHER, PLAIN	3	

CONTINUED ON NEXT FRAME >



68V0010-1080
f115tlra_if115txra



FUEL INJECTION NOZZLE

Ref No.	Part Number	Description	Qty	Remarks
21	68V-14446-00-00	BOLT	1	
22	68V-14265-00-00	COLLAR	3	
23	97095-06010-00	BOLT	4	
24	90430-06014-00	GASKET	4	
25	68V-2247A-00-00	HOSE 1	1	
26	68V-2247B-00-00	HOSE 2	1	
27	68V-2481H-00-00	CLAMP	2	
28	90465-11M10-00	CLAMP	1	



68V0010-1080
f115tlra_if115txra