


FUEL

Ref No.	Part Number	Description	Qty	Remarks
1	6R3-24313-20-00	PIPE 3 (L2820)	1	
2	6R3-24377-10-00	PIPE, JOINT 2	1	
3	90465-11M10-00	CLAMP	2	
4	90465-11M10-00	CLAMP	1	
5	6R3-24560-00-00	FILTER ASSY	1	
6	6R3-24563-00-00	. .ELEMENT, FILTER	1	
7	61N-24521-00-00	. .CUP, FILTER	1	
8	93210-32738-00	. .O-RING	1	
9	648-24566-02-00	BRACKET, FILTER	1	
10	97013-06014-00	BOLT	1	
11	92903-06100-00	WASHER, SPRING	1	
12	95380-08600-00	NUT	1	
13	6G5-24314-00-00	PIPE 4	1	
14	90465-11M10-00	CLAMP	1	
15	90465-11M10-00	CLAMP	1	
16	6E5-24378-00-00	PIPE, JOINT 3	1	
17	6G5-24315-00-00	PIPE 5	1	
18	6E5-24315-00-00	PIPE 5	1	
19	90465-11M10-00	CLAMP	4	
20	6E5-24410-03-00	FUEL PUMP ASSY	2	


CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	6E5-24444-00-00	. .SCREW	3	
22	6E5-24413-00-00	. BODY 2	1	
23	6E5-24471-00-00	. DIAPHRAGM	1	
24	6E5-24435-00-00	. GASKET, BODY 2	1	
25	6E5-24411-00-00	. DIAPHRAGM	1	
26	648-24424-00-00	. .SEAT, SPRING	1	
27	6E5-24423-00-00	. .SPRING, DIAPHRAGM	1	
28	6E5-24434-02-00	. GASKET, BODY	1	
29	6A0-24421-01-00	. .VALVE, CHECK	4	
30	6A0-14325-00-00	. .SCREW, PAN HEAD	4	
31	95380-03600-00	. .NUT	4	
32	6E5-24412-10-00	. BODY 1	1	
33	650-24431-A0-00	GASKET, FUEL PUMP 1	2	
34	97595-06550-00	BOLT, WITH WASHER	4	
35	6G5-24316-10-00	PIPE 6	2	
36	90465-11M10-00	CLAMP	2	
37	90465-11M10-00	CLAMP	2	
38	6G5-24376-00-00	PIPE, JOINT 1	1	
39	6G5-24377-00-00	PIPE, JOINT 2	1	
40	6G5-24317-01-00	PIPE 7	1	

CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
41	6G5-24318-10-00	PIPE, OVERFLOW	2	
42	6G5-24319-10-00	PIPE, OIL	1	
43	90465-11M10-00	CLAMP	5	
44	90465-11M10-00	CLAMP	3	
45	90446-15M07-00	HOSE (L60)	2	