



STARTING MOTOR



Ref No.	Part Number	Description	Qty	Remarks
1	67F-81800-02-00	STARTING MOTOR ASSY	1	
2	67F-81850-00-00	..ARMATURE ASSY	1	
3	67F-81810-00-00	..STATOR ASSY	1	
4	67F-81840-00-00	..BRUSH HOLDER ASSY	1	
5	67F-81801-00-00	...BRUSH SET	1	
6	67F-81813-00-00	...SPRING, BRUSH	4	
7	67F-81820-00-00	..REAR BRACKET ASSY	1	
8	67F-81808-00-00	..PINION ASSY	1	
9	67F-81857-00-00	..PINION STOPPER SET	1	
10	67F-81807-00-00	..GEAR ASSY, STARTING MOTOR	1	
11	67F-81832-00-00	...CLUTCH, OVER RUN	1	
12	67F-81836-00-00	...SHAFT, PINION	1	
13	67F-81821-00-00	...BRACKET, CENTER 1	1	
14	67F-81841-00-00	...BEARING	1	
15	67F-81891-00-00	...GEAR, RING	1	
16	67F-8183R-00-00	...GASKET	1	
17	67F-81830-00-00	...BRACKET, CENTER 2	1	
18	67F-8183T-00-00	...GEAR, IDLER	3	
19	67F-81809-00-00	...WASHER KIT	1	
20	67F-81842-00-00	..COVER	1	

CONTINUED ON NEXT FRAME >

STARTING MOTOR



Ref No.	Part Number	Description	Qty	Remarks
21	67F-81839-00-00	..LEVER ASSY	1	
22	67F-81941-01-00	..STARTER RELAY ASSY	1	
23	67F-81869-00-00	..COVER, DUST	1	
24	6K7-81826-10-00	..BOLT	2	
25	67F-81828-00-00	..SCREW 2	2	
26	67F-81846-00-00	..SCREW	2	
27	97013-08045-00	BOLT	3	
28	92903-08600-00	WASHER, PLATE	3	
29	97013-08016-00	BOLT	1	
30	92903-08600-00	WASHER, PLATE	1	
31	95333-08600-00	NUT	1	
32	92903-08100-00	WASHER, SPRING	1	
33	67F-83627-01-00	LABEL, CAUTION 7	1	