


GENERATOR



Ref No.	Part Number	Description	Qty	Remarks
1	6D8-81450-00-00	ROTOR ASSY	1	
2	6D8-81460-00-00	BASE ASSY	1	
3	6D8-81410-00-00	. .STATOR ASSY	1	
4	63D-81345-20-00	. .SCREW, WITH WASHER (M6X30)	3	
5	97607-04110-00	. .SCREW, WITH WASHER	1	
6	445-81328-20-00	. .CLAMP	1	
7	68V-81673-00-00	ROTOR	1	
8	99530-08012-00	PIN, DOWEL	2	
9	97095-06030-00	BOLT	4	
10	92995-06100-00	WASHER, SPRING	4	
11	92995-06600-00	WASHER	4	
12	90280-05015-00	KEY, WOODRUFF	1	
13	90201-24014-00	WASHER, PLATE	1	
14	90179-24002-00	NUT	1	
15	6D8-81332-00-00	PLATE, TIMING	1	
16	97885-06010-00	SCREW, PAN HEAD	1	
17	92995-06600-00	WASHER	1	
18	6D8-81337-00-00	COVER, FLYWHEEL	1	
19	90480-12072-00	.GROMMET	1	
20	6D8-85547-00-00	DAMPER	1	

CONTINUED ON NEXT FRAME >

GENERATOR

Ref No.	Part Number	Description	Qty	Remarks
21	663-82317-01-00	DAMPER, IGNITION COIL	2	
22	67F-12138-40-00	MARK, CAUTION	1	
23	68V-13437-40-00	MARK, CAUTION	1	
24	6A1-83625-41-00	MARK 5	1	

