



# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
1	6D8-43800-01-8D	POWER TRIM & TILT ASSY	1	
2	67F-43810-01-00	TILT PISTON SUB ASSY	1	
3	67F-4380R-00-00	..CYLINDER END SUB ASSY	1	
4	6H1-43872-10-00	.. RING, BACK UP	1	
5	93210-18397-00	.. O-RING	1	
6	67F-43811-00-00	.. SCREW, CYLINDER END	1	
7	67F-4385A-01-00	..PISTON, TILT	1	
8	93210-29375-00	..O-RING	1	
9	62X-43871-00-00	..RING, BACK UP	1	
10	93501-08001-00	.. BALL	1	
11	93602-07244-00	..PIN, DOWEL	2	
12	67F-22435-00-00	..PLATE, VALVE 2	1	
13	67F-43875-00-00	RING, SNAP	1	
14	6H1-43812-00-00	..SEAL, DUST	1	
15	67F-43821-00-00	..SCREW, TRIM CYLINDER END	1	
16	67F-43861-00-00	..O-RING	1	
17	6H1-43872-10-00	.. RING, BACK UP	1	
18	93210-18397-00	.. O-RING	1	
19	62X-43862-00-00	..O-RING	1	
20	93501-08001-00	..BALL	2	

CONTINUED ON NEXT FRAME >


# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
21	65W-4386A-00-00	. .PIN, ABSORBER VALVE	2	
22	688-4386F-00-00	. .PIN, STRAIGHT	2	
23	65W-43853-00-00	. .SPRING, MAIN VALVE	2	
24	67F-43893-00-00	. .WASHER	1	
25	93503-16003-00	BALL	6	
26	67F-43863-00-00	O-RING	1	
27	93501-08001-00	.BALL	5	
28	67F-43899-00-00	PLATE STOPPER	1	
29	67F-43816-00-00	FILTER 1	1	
30	67F-43862-00-00	O-RING	1	
31	67F-43871-00-00	RING, BACK UP	1	
32	62X-43865-00-00	O-RING	1	
33	67F-4388A-00-00	PISTON, TRIM	1	
34	6T4-4386A-00-00	PIN, ABSORBER VALVE	5	
35	67F-43857-00-00	SPRING, ABSORBER VALVE	5	
36	67F-4381J-00-00	PLATE	1	
37	67F-22471-01-00	CYLINDER, SHOCK ABSORBER	1	
38	67F-4381B-00-00	FREE PISTON SUB ASSY	1	
39	62X-43899-00-00	PLATE STOPPER	1	
40	62X-4384H-00-00	SPRING	2	

CONTINUED ON NEXT FRAME >


# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
41	1UF-22434-00-00	PLATE, VALVE 1	1	
42	62X-43875-00-00	RING, SNAP	1	
43	6D8-4380K-00-00	CYLINDER, TILT SUB ASSY	1	
44	6C6-43817-00-00	FILTER 2	2	
45	69J-4389J-00-00	.O-RING	2	
46	6C5-43816-00-00	FILTER 1	1	
47	6C5-4380G-00-00	PLATE	1	
48	91312-05045-00	BOLT	2	
49	6D8-43830-00-00	GEAR PUMP ASSY	1	
50	6C6-43841-00-00	.PISTON, SHUTTLE	1	
51	6H1-43883-00-00	.O-RING	1	
52	6C6-43894-00-00	.SPRING, SHUTTLE RETURN	2	
53	6C6-4382E-00-00	.ADAPTOR 2	2	
54	93505-32038-00	.BALL	6	
55	6C6-43853-00-00	.SPRING, MAIN VALVE	2	
56	6C6-4387G-00-00	.WASHER	2	
57	69J-4389J-00-00	.O-RING	2	
58	6C5-43851-00-00	.SEAT, RELIEF VALVE	2	
59	6C5-43893-00-00	.WASHER	1	
60	6D8-43855-00-00	.SPRING, UP RELIEF	1	

CONTINUED ON NEXT FRAME >

# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
61	6C6-43893-00-00	..WASHER	1	
62	6C5-4381K-00-00	..HOLDER	1	
63	6D8-43856-00-00	..SPRING, DOWN RELIEF	1	
64	6C5-4382K-00-00	..CAP, RELIEF VALVE	1	
65	6C5-4382L-00-00	..CAP, RELIEF VALVE	1	
66	6C5-43895-00-00	..SEAT, RELIEF VALVE	1	
67	6C5-43854-00-00	..SPRING, MANUAL RELEASE	1	
68	92A08-03110-00	..SCREW SET	1	
69	95302-03600-00	..NUT	2	
70	91312-05030-00	..BOLT	2	
71	6C6-43878-00-00	..BOLT, SOCKET	2	
72	62Y-4387G-00-00	..WASHER	2	
73	91312-04030-00	..BOLT	2	
74	91312-03016-00	..BOLT	1	
75	6C6-4388E-00-00	..PLUG, TAPER SCREW	1	
76	6C6-4388F-00-00	..SPACER	2	
77	6C6-4386G-00-00	..PIN, STRAIGHT 2	1	
78	6C6-4386E-00-00	..LEVER 1	1	
79	91609-50028-00	..PIN, SPRING	2	
80	91312-03005-00	..BOLT	1	

CONTINUED ON NEXT FRAME >

