


FUEL

Ref No.	Part Number	Description	Qty	Remarks
1	6R3-24313-20-00	PIPE 3 (L2820)	1	
2	6R3-24377-10-00	PIPE, JOINT 2	1	
3	90465-11M10-00	CLAMP	2	
4	90465-11M10-00	CLAMP	1	
5	6R3-24560-00-00	FILTER ASSY	1	
6	6R3-24563-00-00	. .ELEMENT, FILTER	1	
7	61N-24521-00-00	. .CUP, FILTER	1	
8	93210-32738-00	. .O-RING	1	
9	648-24566-02-00	BRACKET, FILTER	1	
10	97013-06014-00	BOLT	1	
11	92903-06100-00	WASHER, SPRING	1	
12	95380-08600-00	NUT	1	
13	90465-11M10-00	CLAMP	1	
14	90465-11M10-00	CLAMP	1	
15	6G5-24314-00-00	PIPE 4	1	
16	6E5-24378-00-00	PIPE, JOINT 3	1	
17	6K7-24315-00-00	PIPE 5	1	
18	6E5-24315-00-00	PIPE 5	1	
19	90465-11M10-00	CLAMP	4	
20	6E5-24410-04-00	FUEL PUMP ASSY	2	


CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	6E5-24444-01-00	..SCREW	3	
22	6E5-24413-01-00	..BODY 2	1	
23	6E5-24471-01-00	..DIAPHRAGM	1	
24	6E5-24435-01-00	..GASKET, BODY 2	1	
25	6E5-24411-01-00	..DIAPHRAGM	1	
26	648-24424-00-00	..SEAT, SPRING	1	
27	6E5-24423-00-00	..SPRING, DIAPHRAGM	1	
28	6E5-24412-11-00	..BODY 1	1	
29	6A0-24421-01-00	...VALVE, CHECK	4	
30	6A0-14325-00-00	...SCREW, PAN HEAD	4	
31	95380-03600-00	...NUT	4	
32	6E5-24492-00-00	..BUSH, FUEL PUMP	2	
33	6E5-24486-00-00	..O-RING	2	
34	650-24431-A0-00	GASKET, FUEL PUMP 1	2	
35	97595-06550-00	BOLT, WITH WASHER	4	
36	6G5-24316-10-00	PIPE 6	2	
37	90465-11M10-00	CLAMP	2	
38	90465-11M10-00	CLAMP	2	
39	6E5-24378-00-00	PIPE, JOINT 3	3	
40	90445-13M03-00	HOSE (L50)	1	

CONTINUED ON NEXT FRAME >



FUEL

Ref No.	Part Number	Description	Qty	Remarks
41	90445-13M02-00	HOSE (L40)	1	
42	6K7-24317-00-00	PIPE 7	1	
43	6K7-24318-00-00	PIPE, OVERFLOW	1	
44	6K7-24319-00-00	PIPE, OIL	1	
45	90465-11M10-00	CLAMP	7	
46	90465-11M10-00	CLAMP	3	