


6N44100-D090

## FUEL

Ref No.	Part Number	Description	Qty	Remarks
1	90445-13016-00	HOSE (L2700)	1	
2	6R3-24377-10-00	PIPE, JOINT 2	1	
3	90465-11M10-00	CLAMP	2	
4	90465-11M10-00	CLAMP	1	
5	6R3-24560-00-00	FILTER ASSY	1	
6	6R3-24563-00-00	. .ELEMENT, FILTER	1	
7	61N-24521-00-00	. .CUP, FILTER	1	
8	93210-32738-00	. .O-RING	1	
9	6E5-24566-00-00	BRACKET, FILTER	1	
10	97013-06014-00	BOLT	1	
11	92903-06100-00	WASHER, SPRING	1	
12	95380-08600-00	NUT	1	
13	6E5-24314-00-00	PIPE 4	1	
14	90465-11M10-00	CLAMP	1	
15	90465-11M10-00	CLAMP	1	
16	6E5-24410-04-00	FUEL PUMP ASSY	1	
17	6E5-24444-01-00	. .SCREW	3	
18	6E5-24413-01-00	. .BODY 2	1	
19	6E5-24471-01-00	. .DIAPHRAGM	1	
20	6E5-24435-01-00	. .GASKET, BODY 2	1	

CONTINUED ON NEXT FRAME >



6N44100-D090

# FUEL

Ref No.	Part Number	Description	Qty	Remarks
21	6E5-24411-01-00	..DIAPHRAGM	1	
22	648-24424-00-00	..SEAT, SPRING	1	
23	6E5-24423-00-00	..SPRING, DIAPHRAGM	1	
24	6E5-24412-11-00	..BODY 1	1	
25	6A0-24421-01-00	...VALVE, CHECK	4	
26	6A0-14325-00-00	...SCREW, PAN HEAD	4	
27	95380-03600-00	...NUT	4	
28	6E5-24492-00-00	..BUSH, FUEL PUMP	2	
29	6E5-24486-00-00	..O-RING	2	
30	650-24431-A0-00	GASKET, FUEL PUMP 1	1	
31	97595-06550-00	BOLT, WITH WASHER	2	
32	6G5-24316-10-00	PIPE 6	1	
33	90465-11M10-00	CLAMP	1	
34	90465-11M10-00	CLAMP	1	
35	6E5-24376-10-00	PIPE, JOINT 1	1	
36	6G5-24318-10-00	PIPE, OVERFLOW	1	
37	6G5-24319-10-00	PIPE, OIL	1	
38	90465-11M10-00	CLAMP	2	
39	90465-11M10-00	CLAMP	2	
40	90446-15M07-00	HOSE (L60)	1	