


BOTTOM COWLING





Ref No.	Part Number	Description	Qty	Remarks
1	6L2-42711-03-4D	COWLING, BOTTOM 1	1	
2	6L2-42815-01-4D	LEVER, CLAMP	1	
3	90386-12M45-00	BUSH	2	
4	6L2-42816-00-00	LEVER, CLAMP	1	
5	90206-12052-00	WASHER, WAVE	1	
6	97880-06035-00	SCREW, PAN HEAD	1	
7	95780-06300-00	NUT, FLANGE	1	
8	6L2-42719-10-00	PANEL, FRONT LOWER	0	
8	6L2-42719-00-00	PANEL, FRONT LOWER	1	
9	6L2-42724-00-00	GROMMET	1	
10	90170-12M13-00	NUT	1	
11	689-41273-00-00	GROMMET	1	
12	6J8-41274-00-00	GROMMET 2	1	
13	6L2-42725-00-00	GROMMET	1	
13	6L2-42725-40-00	GROMMET	0	
13	6L2-42725-50-00	GROMMET	0	
14	6G1-42724-00-00	GROMMET	1	
15	6L2-42726-10-00	GROMMET	0	
15	6L2-42726-01-00	GROMMET	1	
16	6G1-42727-00-00	GROMMET	1	

CONTINUED ON NEXT FRAME >

BOTTOM COWLING

Ref No.	Part Number	Description	Qty	Remarks
17	6L2-42748-01-00	GROMMET	1	
18	6L2-42716-00-00	RUBBER, SEAL 1	1	
19	90338-05M03-00	PLUG	2	
20	90480-15M31-00	GROMMET	4	
21	90387-06M52-00	COLLAR	4	
22	95895-06020-00	BOLT, FLANGE	4	
23	6L2-42738-01-00	PLATE, FITTING	2	
24	6BL-44391-00-00	NIPPLE, HOSE	1	
25	6E5-82588-00-00	PLATE	0	
26	95895-06016-00	BOLT, FLANGE	0	
27	6L2-82575-00-00	ENGINE STOP SWITCH ASSY	1	
28	682-82556-00-00	. .LANYARD, STOP SWITCH	1	
29	689-8257Y-00-00	. .CAP	1	
30	6E7-42791-00-00	MARK 1	1	
31	6AH-42794-40-00	LABEL, WARNING (GENERAL)	1	



6L28110-H130