


STARTING MOTOR

Ref No.	Part Number	Description	Qty	Remarks
1	6L2-81800-20-00	STARTING MOTOR ASSY	0	
2	6L2-81850-20-00	..ARMATURE ASSY	0	
3	682-81809-10-00	..WASHER KIT	0	
4	6L2-81833-10-00	..RING, STOP	0	
5	682-81810-11-00	..STATOR ASSY	0	
6	6L2-81820-20-00	..REAR BRACKET ASSY	0	
7	6L2-81840-20-00	...BRUSH HOLDER ASSY	0	
8	682-81813-10-00	...SPRING, BRUSH	0	
9	6L2-81811-20-00	...BRUSH 1	0	
10	6L2-81812-20-00	...BRUSH 2	0	
11	682-81832-20-00	..CLUTCH, OVER RUN	0	
12	682-81830-11-00	..FRONT BRACKET ASSY	0	
13	682-81831-00-00	...METAL, FRONT	0	
14	682-81826-10-00	..BOLT	0	
15	682-81847-10-00	..O-RING	0	
16	682-81834-10-00	..RING	0	
17	97013-08025-00	BOLT	0	
18	92903-08600-00	WASHER, PLATE	0	



6L20010-4120