


# POWER TILT ASSY




6AV2110-H270

Ref No.	Part Number	Description	Qty	Remarks
1	69G-43840-02-4D	POWER TILT ASSY	0	UR PH/PR
2	69A-4380K-00-00	..CYLINDER, TILT SUB ASSY	0	
3	69A-22471-00-00	..CASE, CYLINDER	0	
4	93210-27666-00	..O-RING	0	
5	6H1-4388E-11-00	..PLUG, TAPER SCREW	0	
6	93210-07003-00	..O-RING	0	
7	69A-43814-00-00	..PISTON, FREE	0	
8	93210-21276-00	...O-RING	0	
9	69A-43872-00-00	...RING, BACK UP	0	
10	69A-43810-00-00	..TILT PISTON SUB ASSY	0	
11	69A-4380D-00-00	...PISTON COMP.	0	
12	93210-21276-00	...O-RING	0	
13	69A-43872-00-00	...RING, BACK UP	0	
14	93505-32038-00	...BALL	0	
15	65W-4386A-00-00	...PIN, ABSORBER VALVE	0	
16	93604-06136-00	...PIN, DOWEL	0	
17	69A-43857-00-00	...SPRING, ABSORBER VALVE	0	
18	69A-43801-00-00	...ROD	0	
19	69A-43811-01-00	...SCREW, CYLINDER END	0	
20	6H1-43866-00-00	...O-RING	0	

CONTINUED ON NEXT FRAME >

# POWER TILT ASSY




6AV2110-H270

Ref No.	Part Number	Description	Qty	Remarks
21	69A-43871-00-00	...RING, BACK UP	0	
22	69A-43812-00-00	...SEAL, DUST	0	
23	69A-43869-00-00	...O-RING	0	
24	69A-43830-00-00	..GEAR PUMP ASSY	0	
25	69A-4380C-00-00	...GEAR HOUSING ASSY	0	
26	69A-43841-00-00	..PISTON, SHUTTLE	0	
27	69A-4384M-00-00	..PISTON, SHUTTLE 2	0	
28	62Y-43894-00-00	..SPRING, SHUTTLE RETURN	0	
29	69A-4384F-00-00	..SEAL, MAIN VALVE	0	
30	6H1-43883-00-00	..O-RING	0	
31	99002-03600-00	..CLIP	0	
32	69G-4382G-00-00	..VALVE SEAT	0	
33	93210-12N52-00	...O-RING	0	
34	6T4-43808-00-00	..SEAT VALVE COMP. 1	0	
35	69G-43853-00-00	..SPRING, MAIN VALVE	0	
36	69J-4381C-00-00	..FILTER 3	0	
37	6H1-4384G-11-00	..SEAL, RELIEF VALVE	0	
38	6H1-43844-10-00	..PIN, VALVE SUPPORT	0	
39	69A-43855-00-00	..SPRING, UP RELIEF	0	
40	6H1-43856-10-00	..SPRING, DOWN RELIEF	0	

CONTINUED ON NEXT FRAME >

# POWER TILT ASSY




6AV2110-H270

Ref No.	Part Number	Description	Qty	Remarks
41	93501-08001-00	..BALL	0	
42	69A-4386A-00-00	..PIN, ABSORBER VALVE	0	
43	69A-43824-00-00	..SPRING, DOWN RELIEF 2	0	
44	69A-43848-00-00	..ROD, MANUAL RELEASE	0	
45	93602-15250-00	..PIN, DOWEL	0	
46	93210-06001-00	..O-RING	0	
47	69A-43854-00-00	..SPRING, MANUAL RELEASE	0	
48	69A-4381G-00-00	..PIN 1	0	
49	93501-08001-00	..BALL	0	
50	6H1-43883-00-00	..O-RING	0	
51	69A-4384H-00-00	..SPRING	0	
52	93606-14081-00	..PIN, DOWEL	0	
53	91312-05025-00	..BOLT	0	
54	69A-43816-01-00	..FILTER 1	0	
55	N35-43862-10-00	..O-RING	0	
56	69A-23129-00-00	..GASKET, DRAIN PLUG	0	
57	69A-43878-00-00	..BOLT, SOCKET	0	
58	69G-43880-01-00	..MOTOR ASSY	0	
59	65W-43804-01-00	...STATOR ASSY	0	
60	65W-43887-01-00	...BOLT	0	

CONTINUED ON NEXT FRAME >

# POWER TILT ASSY



Ref No.	Part Number	Description	Qty	Remarks
61	65W-43805-01-00	...ARMATURE ASSY	0	
62	65W-4387G-00-00	...WASHER	0	
63	69G-43881-01-00	...FRAME, END	0	
64	65W-82181-00-00	...CIRCUIT BREAKER COMP.	0	
65	65W-43892-01-00	...BRUSH 2	0	
66	65W-43891-01-00	...BRUSH 1	0	
67	65W-4386K-01-00	...SPRING, BRUSH	0	
68	65W-4386L-00-00	...SPRING, BRUSH 2	0	
69	65W-4380F-01-00	...PLATE, BRUSH HOLDER	0	
70	65W-43879-01-00	...SCREW, WITH WASHER	0	
71	65W-43882-01-00	...OIL SEAL	0	
72	69G-4388F-00-00	..SPACER	0	