


# FUEL INJECTION PUMP

Ref No.	Part Number	Description	Qty	Remarks
1	60V-12170-00-00	CAMSHAFT ASSY 1	1	
2	60V-12424-00-00	..PLATE, CARTRIDGE INNER	1	
3	93306-00001-00	...BEARING	1	
4	68F-12173-00-00	..CAP, CAMSHAFT 1	1	
5	93306-001U0-00	...BEARING	1	
6	68F-12223-00-00	...SEAL	1	
7	68F-12439-00-00	..O-RING	1	
8	60V-12171-00-00	..CAMSHAFT 1	1	
9	68F-12228-00-00	..BOLT	3	
10	68F-13455-00-00	..PLUG	3	
11	68F-13473-00-00	..O-RING	3	
12	68F-12228-00-00	BOLT	4	
13	60V-13993-00-00	COVER, CONTROL RACK	1	
14	60W-13993-00-00	COVER, CONTROL RACK	1	
15	65L-14565-00-00	SCREW	2	
16	68F-24579-00-00	WASHER 2	12	
17	60V-13854-00-00	PLATE 4	2	
18	60V-13910-00-00	FUEL PUMP ASSY	2	
19	60V-14005-00-00	..RING, SEAL	1	
20	60V-14126-00-00	..GASKET	1	


CONTINUED ON NEXT FRAME >



## FUEL INJECTION PUMP

Ref No.	Part Number	Description	Qty	Remarks
21	68F-24300-00-00	FUEL PIPE JOINT	1	
22	60V-24178-00-00	BOLT 3	4	
23	60V-24176-00-00	BOLT 1	8	
24	60V-24378-00-00	PIPE, JOINT 3	1	
25	60V-24864-00-00	TUBE	1	
26	60V-2510T-00-00	TUBE	1	
27	68F-13815-10-00	JOINT 1	2	
28	68F-2466A-00-00	..PACKING KIT	2	
29	68F-13816-10-00	JOINT 2	2	
30	68F-24486-00-00	..O-RING	1	
31	68F-24329-00-00	..SEAL	1	
32	60V-13505-00-00	JOINT COMP.	4	
33	68F-13473-00-00	..O-RING	1	
34	60V-13473-00-00	..O-RING	1	
35	60V-14148-00-00	PIPE	1	
36	65L-24387-00-00	..CLIP	2	
37	60V-24312-00-00	PIPE 2	1	
38	68F-24356-00-00	..CLIP, PIPE 1	2	
39	60V-24313-00-00	PIPE 3	1	
40	68F-24356-00-00	..CLIP, PIPE 1	2	

CONTINUED ON NEXT FRAME >



# FUEL INJECTION PUMP

Ref No.	Part Number	Description	Qty	Remarks
41	60V-14149-00-00	PIPE	1	
42	65L-24387-00-00	..CLIP	2	
43	60V-24314-00-00	PIPE 4	1	
44	68F-24356-00-00	..CLIP, PIPE 1	2	
45	60V-24315-00-00	PIPE 5	1	
46	68F-24356-00-00	..CLIP, PIPE 1	2	
47	60V-13972-00-00	PIPE, FUEL 2	1	
48	65L-24387-00-00	..CLIP	2	
49	60X-24864-00-00	TUBE	1	
50	60V-2466A-00-00	PACKING KIT	1	