



# POWER TRIM TILT ASSY



Ref No.	Part Number	Description	Qty	Remarks
1	65W-43800-03-4D	POWER TRIM & TILT ASSY	1	
2	65W-43880-01-00	..MOTOR ASSY	1	
3	65W-43804-01-00	...STATOR ASSY	1	
4	65W-43887-01-00	...BOLT	2	
5	65W-43805-01-00	...ARMATURE ASSY	1	
6	65W-4387G-00-00	...WASHER	1	
7	65W-43881-01-00	...FRAME, END	1	
8	65W-82181-00-00	...CIRCUIT BREAKER COMP.	1	
9	65W-43892-01-00	...BRUSH 2	1	
10	65W-43891-01-00	...BRUSH 1	1	
11	65W-4386K-01-00	...SPRING, BRUSH	1	
12	65W-4386L-00-00	...SPRING, BRUSH 2	1	
13	65W-4380F-01-00	...PLATE, BRUSH HOLDER	1	
14	65W-43879-01-00	...SCREW, WITH WASHER	2	
15	65W-43882-01-00	...OIL SEAL	1	
16	65W-43840-00-00	..POWER TILT ASSY	1	
17	65W-4380K-00-00	...CYLINDER, TILT SUB ASSY	1	
18	65W-43810-00-00	...TILT PISTON SUB ASSY	1	
19	65W-43812-00-00	...SEAL, DUST	1	
20	65W-43865-00-00	...O-RING	1	

CONTINUED ON NEXT FRAME >


# POWER TRIM TILT ASSY



Ref No.	Part Number	Description	Qty	Remarks
21	6H1-43861-10-00	...O-RING	1	
22	65W-43871-00-00	...RING, BACK UP	1	
23	65W-4381B-00-00	...FREE PISTON SUB ASSY	1	
24	6H1-43861-10-00	...O-RING	1	
25	93210-11368-00	.. O-RING	3	
26	6H1-43816-00-00	.. FILTER 1	1	
27	93210-064A5-00	...O-RING	4	
28	65W-4380L-00-00	..HOUSING, TRIM & TILT SUB ASSY	1	
29	65W-43888-00-00	.. BOLT, SOCKET	4	
30	93210-50768-00	..O-RING	1	
31	6T4-43802-03-00	..VALVE SUB ASSY	2	
32	6H1-43866-01-00	...O-RING	1	
33	93210-10M74-00	.. O-RING	1	
34	93210-12N52-00	...O-RING	1	
35	62X-43841-00-00	..PISTON, SHUTTLE	1	
36	93210-09165-00	.. O-RING	3	
37	65W-43831-00-00	..CONNECTOR, SHAFT	1	
38	65W-43830-00-00	..GEAR PUMP ASSY	1	
39	6T4-43853-00-00	..SPRING, MAIN VALVE	1	
40	91318-04025-00	..BOLT	4	

CONTINUED ON NEXT FRAME >


# POWER TRIM TILT ASSY



Ref No.	Part Number	Description	Qty	Remarks
41	65W-43817-00-00	..FILTER 2	2	
42	93210-04N50-00	..O-RING	2	
43	93210-04N51-00	..O-RING	2	
44	6H1-43875-00-00	..RING, SNAP	1	
45	6H1-43845-00-00	..SCREW, MANUAL RELEASE	1	
46	6D8-43863-00-00	..O-RING	1	
47	6H1-43847-00-00	..SEAT, MANUAL VALVE	2	
48	65W-43854-00-00	..SPRING, MANUAL RELEASE	1	
49	65W-4382A-00-00	..ADAPTOR 1	1	
50	65W-43844-00-00	..PIN, VALVE SUPPORT	1	
51	65W-43851-00-00	..SEAT, RELIEF VALVE	1	
52	93210-08006-00	..O-RING	1	
53	93210-03478-00	..O-RING	1	
54	65W-43855-00-00	..SPRING, UP RELIEF	1	
55	93210-11073-00	..O-RING	1	
56	65W-43843-00-00	..SCREW, VALVE LOCK	1	
57	6H1-43856-10-00	..SPRING, DOWN RELIEF	1	
58	6H1-43844-10-00	..PIN, VALVE SUPPORT	1	
59	6H1-4384F-10-00	..SEAL, MAIN VALVE	1	
60	65W-4386A-00-00	..PIN, ABSORBER VALVE	2	

CONTINUED ON NEXT FRAME >

# POWER TRIM TILT ASSY



Ref No.	Part Number	Description	Qty	Remarks
61	93501-08001-00	. .BALL	2	
62	65W-43853-00-00	. .SPRING, MAIN VALVE	2	
63	6H1-43829-00-00	. .PLUG, RESERVOIR	1	
64	62X-43878-00-00	. .BOLT, SOCKET	3	
65	93210-10M74-00	. .O-RING	1	
66	6T4-43808-00-00	. .SEAT VALVE COMP. 1	1	