



# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
1	6C5-43800-10-8D	POWER TRIM & TILT ASSY	1	
2	6C5-43810-01-00	TILT PISTON SUB ASSY	1	
3	6C5-43801-01-00	. .ROD	1	
4	62Y-43822-00-00	. .SEAL, TRIM DUST	1	
5	6C5-43821-01-00	. .SCREW, TRIM CYLINDER END	1	
6	62Y-43863-00-00	. .O-RING	1	
7	6CJ-43863-00-00	. .O-RING	2	
8	6C5-43862-00-00	. .O-RING	1	
9	6C5-43861-00-00	. O-RING	1	
10	6C5-43871-00-00	. .RING, BACK UP	1	
11	6C5-22471-00-00	CYLINDER, SHOCK ABSORBER	1	
12	6C5-43875-00-00	RING, SNAP	1	
13	6C5-4381B-00-00	FREE PISTON SUB ASSY	1	
14	93450-32116-00	CIRCLIP	1	
15	6C5-43899-00-00	PLATE STOPPER	1	
16	93503-16003-00	.BALL	6	
17	62X-4384H-00-00	SPRING	2	
18	6C5-22435-00-00	PLATE, VALVE 2	1	
19	99009-32500-00	CIRCLIP	1	
20	6C5-43861-00-00	O-RING	1	

CONTINUED ON NEXT FRAME >


# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
21	6C5-4380K-01-00	CYLINDER, TILT SUB ASSY	1	
22	6C5-43817-10-00	FILTER 2	2	
23	69J-4389J-00-00	.O-RING	2	
24	6C5-43816-00-00	FILTER 1	1	
25	6C5-4380G-00-00	PLATE	1	
26	91318-05045-00	BOLT	4	
27	6C5-43830-01-00	GEAR PUMP ASSY	1	
28	6D8-43841-00-00	.PISTON, SHUTTLE	1	
29	6H1-43883-00-00	.O-RING	1	
30	69J-43894-00-00	.SPRING, SHUTTLE RETURN	2	
31	6D8-4384M-00-00	.PISTON, SHUTTLE 2	1	
32	69A-4384F-00-00	.SEAL, MAIN VALVE	2	
33	99002-03600-00	.CIRCLIP	2	
34	6EK-4382E-00-00	.ADAPTOR 2	2	
35	6C6-4387G-00-00	.WASHER	2	
36	6C6-43853-00-00	.SPRING, MAIN VALVE	2	
37	93505-32038-00	.BALL	6	
38	69J-4389J-00-00	.O-RING	2	
39	6D8-43851-00-00	.SEAT, RELIEF VALVE	1	
40	93210-064A5-00	.O-RING	1	

CONTINUED ON NEXT FRAME >

# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
41	6C5-43855-10-00	..SPRING, UP RELIEF	1	
42	93501-08001-00	..BALL	2	
43	6D8-43844-00-00	..PIN, VALVE SUPPORT	1	
44	6D8-43843-00-00	..SCREW, VALVE LOCK	1	
45	93210-04N51-00	..O-RING	1	
46	6H1-4384G-11-00	..SEAL, RELIEF VALVE	1	
47	6H1-43844-10-00	..PIN, VALVE SUPPORT	1	
48	6C5-43856-10-00	..SPRING, DOWN RELIEF	1	
49	6D8-4382L-00-00	..CAP, RELIEF VALVE	1	
50	6C5-43895-00-00	..SEAT, RELIEF VALVE	1	
51	6C5-43854-00-00	..SPRING, MANUAL RELEASE	1	
52	93604-26256-00	..PIN, DOWEL	2	
53	91318-05030-00	..BOLT	2	
54	91318-03025-00	..BOLT	2	
55	91318-03005-00	..BOLT	1	
56	6D8-43863-00-00	O-RING	1	
57	6H1-43875-00-00	RING, SNAP	1	
58	6C5-43845-00-00	SCREW, MANUAL RELEASE	1	
59	93210-09165-00	O-RING	1	
60	6H1-43829-00-00	PLUG, RESERVOIR	1	

CONTINUED ON NEXT FRAME >

