


# POWER TILT ASSY




6AG3110-H260

Ref No.	Part Number	Description	Qty	Remarks
1	6AH-43840-01-8D	POWER TILT ASSY	0	
2	6AH-4380K-00-00	..CYLINDER, TILT SUB ASSY	0	
3	6AH-22471-00-00	.. CYLINDER, SHOCK ABSORBER	0	
4	93210-320A7-00	.. O-RING	0	
5	6H1-4388E-11-00	.. PLUG, TAPER SCREW	0	
6	93210-07003-00	.. O-RING	0	
7	6AH-43814-00-00	.. PISTON, FREE	0	
8	93210-24709-00	.. O-RING	0	
9	6C5-43871-00-00	.. RING, BACK UP	0	
10	6AH-43810-00-00	.. TILT PISTON SUB ASSY	0	
11	6AH-4380D-00-00	.. PISTON COMP.	0	
12	93210-24709-00	... O-RING	0	
13	6C5-43871-00-00	.. RING, BACK UP	0	
14	93501-08001-00	.. BALL	0	
15	6AH-4386A-00-00	.. PIN, ABSORBER VALVE	0	
16	6AH-4385E-00-00	.. PLATE, PISTON	0	
17	92902-06200-00	.. WASHER	0	
18	6AH-43878-00-00	.. BOLT, SOCKET	0	
19	6AH-43857-00-00	.. SPRING, ABSORBER VALVE	0	
20	6AH-43801-00-00	.. ROD	0	

CONTINUED ON NEXT FRAME >


# POWER TILT ASSY



Ref No.	Part Number	Description	Qty	Remarks
21	6AH-43811-00-00	. . SCREW, CYLINDER END	0	
22	6H1-43866-01-00	. . O-RING	0	
23	69A-43871-00-00	. . RING, BACK UP	0	
24	69A-43812-00-00	. . SEAL, DUST	0	
25	62X-43862-00-00	. . O-RING	0	
26	6AH-43830-00-00	. GEAR PUMP ASSY	0	
27	69A-43841-00-00	. PISTON, SHUTTLE	0	
28	69A-4384M-00-00	. PISTON, SHUTTLE 2	0	
29	62Y-43894-00-00	. SPRING, SHUTTLE RETURN	0	
30	69A-4384F-00-00	. SEAL, MAIN VALVE	0	
31	6H1-43883-00-00	. O-RING	0	
32	99002-03600-00	. CIRCLIP	0	
33	69G-4382G-00-00	. VALVE SEAT	0	
34	93210-12N52-00	. O-RING	0	
35	6T4-43808-00-00	. SEAT VALVE COMP. 1	0	
36	69G-43853-00-00	. SPRING, MAIN VALVE	0	
37	69G-4388F-00-00	. SPACER	0	
38	69J-4381C-00-00	. FILTER 3	0	
39	6H1-4384G-11-00	. SEAL, RELIEF VALVE	0	
40	6H1-43844-10-00	. PIN, VALVE SUPPORT	0	

CONTINUED ON NEXT FRAME >

# POWER TILT ASSY



6AG3110-H260

Ref No.	Part Number	Description	Qty	Remarks
41	6F2-43855-00-00	. SPRING, UP RELIEF	0	
42	6H1-43856-10-00	. SPRING, DOWN RELIEF	0	
43	93501-08001-00	. BALL	0	
44	69A-4386A-00-00	. PIN, ABSORBER VALVE	0	
45	69A-43824-00-00	. SPRING, DOWN RELIEF 2	0	
46	69A-43848-00-00	. ROD, MANUAL RELEASE	0	
47	93602-15250-00	. PIN, DOWEL	0	
48	93210-06001-00	. O-RING	0	
49	6AH-43854-00-00	. SPRING, MANUAL RELEASE	0	
50	69A-4381G-00-00	. PIN 1	0	
51	93501-08001-00	. BALL	0	
52	6H1-43883-00-00	. O-RING	0	
53	69A-4384H-00-00	. SPRING	0	
54	93606-14081-00	. PIN, DOWEL	0	
55	91312-05025-00	. BOLT, HEXAGON SOCKET HEAD	0	
56	69J-4381C-00-00	. FILTER 3	0	
57	6AH-4381J-00-00	. PLATE	0	
58	N35-43862-10-00	. O-RING	0	
59	69A-23129-00-00	. GASKET, DRAIN PLUG	0	
60	69A-43878-00-00	. BOLT, SOCKET	0	

CONTINUED ON NEXT FRAME >

