


# STARTING MOTOR



Ref No.	Part Number	Description	Qty	Remarks
1	6AH-81800-01-00	STARTING MOTOR ASSY	0	
2	689-81850-11-00	. ARMATURE ASSY	0	
3	689-81809-11-00	. WASHER KIT	0	
4	689-81810-11-00	. STATOR ASSY	0	
5	689-81847-11-00	. O-RING	0	
6	689-81840-11-00	. BRUSH HOLDER ASSY	0	
7	689-81811-11-00	.. BRUSH 1	0	
8	689-81812-11-00	.. BRUSH 2	0	
9	689-81813-10-00	.. SPRING, BRUSH	0	
10	6AH-81820-01-00	. REAR BRACKET ASSY	0	
11	689-81807-12-00	. GEAR ASSY, STARTING MOTOR	0	
12	68T-81857-00-00	. PINION STOPPER SET	0	
13	6AH-81830-00-00	. FRONT BRACKET ASSY	0	
14	689-81826-10-00	. BOLT	0	
15	97013-08045-00	BOLT	0	
16	92903-08600-00	WASHER, PLATE	0	
17	97013-08035-00	BOLT	0	
18	92903-08600-00	WASHER, PLATE	0	
19	97095-08016-00	BOLT	0	
20	92995-08600-00	WASHER	0	

CONTINUED ON NEXT FRAME >

# STARTING MOTOR

Ref No.	Part Number	Description	Qty	Remarks
21	6AH-81942-00-00	COVER	0	
22	6AH-82581-00-00	STAY, CORD CLAMP	0	
23	97095-06014-00	BOLT	0	
24	92995-06600-00	WASHER	0	

