


STEERING

Ref No.	Part Number	Description	Qty	Remarks
1	6BP-W0084-00-8D	HANDLE STEERING ASSY	1	
2	6AH-42101-02-8D	HANDLE, STEERING	1	
3	90109-06M86-00	. BOLT	2	
4	6AH-26288-00-00	GROMMET, CABLE	1	
5	66M-42119-01-00	GRIP, STEERING HANDLE	1	
6	67D-42177-00-00	RUBBER, HANDLE	1	
7	65W-42138-00-00	LEVER, THROTTLE	1	
8	90152-05011-00	SCREW, COUNTERSUNK	1	
9	65W-42159-00-00	STAY	1	
10	6G1-42126-00-00	FRICTION, STEERING HANDLE GRIP	1	
11	65W-42125-00-00	BOLT, FRICTION ADJUSTING	1	
12	91490-16010-00	PIN. COTTER	1	
13	6J0-42137-10-00	INDICATOR, THROTTLE	1	
14	6X4-44188-00-00	WASHER	2	
15	90501-23215-00	SPRING, COMPRESSION	1	
16	90386-08004-00	BUSH	1	
17	6BP-26311-00-00	CABLE, THROTTLE 1	2	
18	6BP-26316-00-00	BOOT, THROTTLE CABLE	1	
19	6AH-44554-00-00	PLATE	1	
20	97095-06014-00	BOLT	1	

CONTINUED ON NEXT FRAME >




STEERING

Ref No.	Part Number	Description	Qty	Remarks
21	92995-06600-00	WASHER	1	
22	6AH-2634E-00-00	PROTECTOR 1	1	
23	90386-45001-00	BUSH	1	
24	90201-39008-00	WASHER, PLATE	2	
25	90206-39001-00	WASHER, WAVE	2	
26	90381-20001-00	BUSH, SOLID	1	
27	6AH-42131-00-8D	COVER, HANDLE STEERING	1	
28	97595-06555-00	BOLT, WITH WASHER	2	
29	6BL-42532-00-00	COVER	1	
30	6BL-42131-00-00	COVER, HANDLE STEERING	1	
31	90111-06072-00	BOLT,HEX. SOCKET BUTTON	3	
32	6BL-82594-00-00	CLAMP	1	
33	90387-06M53-00	COLLAR	1	
34	90111-06133-00	BOLT,HEX. SOCKET BUTTON	1	
34	90111-06072-00	BOLT,HEX. SOCKET BUTTON	0	
35	6BL-42121-00-8D	BRACKET	1	
36	6AH-44111-00-00	HANDLE, GEAR SHIFT	1	
37	90119-06M05-00	BOLT, WITH WASHER	1	
38	90387-06M86-00	.COLLAR	1	
39	90206-15M18-00	WASHER, WAVE	1	

CONTINUED ON NEXT FRAME >

STEERING



Ref No.	Part Number	Description	Qty	Remarks
40	6BL-44124-00-00	LINK, SHIFT ROD	1	
41	92990-06200-00	WASHER, PLAIN	1	
42	90468-18008-00	.CLIP	1	
43	6G8-44191-00-00	INDICATOR, SHIFT	1	
44	6BL-82575-00-00	ENGINE STOP SWITCH ASSY	1	
45	682-82556-00-00	..LANYARD, STOP SWITCH	1	
46	689-8257Y-00-00	..CAP	1	