


GENERATOR



Ref No.	Part Number	Description	Qty	Remarks
1	6D8-81450-00-00	ROTOR ASSY	1	
2	6D8-81460-00-00	BASE ASSY	1	
3	6D8-85580-00-00	. .COIL, PULSER	1	
4	6D8-81410-00-00	. .STATOR ASSY	1	
5	63D-81345-20-00	. .SCREW, WITH WASHER (M6X30)	3	
6	97607-04110-00	. .SCREW, WITH WASHER	1	
7	445-81328-20-00	. .CLAMP	1	
8	68V-81673-10-00	ROTOR	1	
9	99530-08012-00	.PIN, DOWEL	2	
10	97595-06630-00	BOLT, WITH WASHER	4	
11	90280-05015-00	KEY, WOODRUFF	1	
12	90201-24014-00	WASHER, PLATE	1	
13	90179-24002-00	NUT	1	
14	6D8-81332-00-00	PLATE, TIMING	1	
15	97985-06210-00	SCREW, WITH WASHER	1	
16	6D8-81337-00-00	COVER, FLYWHEEL	1	
17	90480-12314-00	GROMMET	1	
18	6D8-85547-00-00	DAMPER	1	
19	663-82317-01-00	DAMPER, IGNITION COIL	2	
20	90387-06119-00	COLLAR	2	

CONTINUED ON NEXT FRAME >

GENERATOR

Ref No.	Part Number	Description	Qty	Remarks
21	95895-06020-00	BOLT, FLANGE	2	
22	68V-13437-52-00	MARK, CAUTION	1	
23	6EE-81995-40-00	LABEL, WARNING	1	
24	6EE-81995-50-00	LABEL, WARNING	1	
25	6EE-81994-40-00	LABEL, SAFETY	1	
26	6EE-81994-50-00	LABEL, SAFETY	1	

