





# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
21	93503-16003-00	.BALL	6	
22	67F-43863-00-00	O-RING	1	
23	93501-08001-00	.BALL	5	
24	67F-43899-00-00	PLATE STOPPER	1	
25	67F-43816-00-00	FILTER 1	1	
26	67F-43862-00-00	O-RING	1	
27	67F-43865-00-00	.O-RING	1	
28	67F-4388A-01-00	PISTON, TRIM	1	
29	6T4-4386A-00-00	PIN, ABSORBER VALVE	5	
30	67F-43857-00-00	SPRING, ABSORBER VALVE	5	
31	67F-4381J-00-00	PLATE	1	
32	67F-22471-01-00	CYLINDER, SHOCK ABSORBER	1	
33	67F-4381B-00-00	FREE PISTON SUB ASSY	1	
34	62X-43899-00-00	PLATE STOPPER	1	
35	62X-4384H-00-00	SPRING	2	
36	1UF-22434-00-00	PLATE, VALVE 1	1	
37	62X-43875-00-00	RING, SNAP	1	
38	6D8-4380K-02-00	CYLINDER, TILT SUB ASSY	1	
39	6C5-43817-10-00	FILTER 2	2	
40	69J-4389J-00-00	.O-RING	2	

CONTINUED ON NEXT FRAME >

# POWER TRIM TILT ASSY 1



Ref No.	Part Number	Description	Qty	Remarks
41	6C5-43816-00-00	FILTER 1	1	
42	6C5-4380G-00-00	PLATE	1	
43	91318-05045-00	BOLT	4	
44	6D8-43830-01-00	GEAR PUMP ASSY	1	
45	69J-4389J-00-00	..O-RING	2	
46	6D8-43841-00-00	..PISTON, SHUTTLE	1	
47	93501-08001-00	..BALL	2	
48	99002-03600-00	..CIRCLIP	2	
49	69A-4384F-00-00	..SEAL, MAIN VALVE	2	
50	93505-32038-00	..BALL	6	
51	6EK-4382E-00-00	..ADAPTOR 2	2	
52	6C6-4387G-00-00	..WASHER	2	
53	6D8-43851-00-00	..SEAT, RELIEF VALVE	1	
54	6H1-4384G-11-00	..SEAL, RELIEF VALVE	1	
55	93210-064A5-00	..O-RING	1	
56	93210-04N51-00	..O-RING	1	
57	6H1-43844-10-00	..PIN, VALVE SUPPORT	1	
58	6D8-43844-00-00	..PIN, VALVE SUPPORT	1	
59	6EK-43856-00-00	..SPRING, DOWN RELIEF	1	
60	6C5-43855-10-00	..SPRING, UP RELIEF	1	

CONTINUED ON NEXT FRAME >



