


CONTROL 703 PULL

703 REMOTE CONTROL (PULL TO OPEN TYPE)




Ref No.	Part Number	Description	Qty	Remarks
1	703-48230-21-00	REMOTE CONTROL ASSY (7P)	1	UR WITHOUT PT/T SW.
2	703-48232-00-00	..GEAR	1	
3	703-48271-00-00	..ARM, SHIFT	1	
4	703-48261-11-00	..ARM, THROTTLE	1	
5	703-48235-00-00	..BUSHING	1	
6	703-48152-10-00	..KNOB, FREE ACCEL.	1	
7	703-48268-00-00	..SPACER	1	
8	703-48264-00-00	..FRICTION, THROTTLE	1	
9	95380-05600-00	..NUT	1	
10	97380-05025-00	..BOLT	1	
11	703-48265-10-00	..SHAFT, FRICTION	1	
12	93430-06024-00	..CIRCLIP	3	
13	703-48245-00-00	..PLATE, LOCK	1	
14	703-48252-00-00	..ROLLER, CAM	1	
15	701-48248-00-00	..ROLLER, FREE ACCEL.	1	
16	703-48198-00-00	..WASHER, WAVE	1	
17	703-48243-00-00	..BUSHING	1	
18	703-48236-00-00	..BUSHING 1	2	
19	703-48189-00-00	..RETAINER	1	
20	703-48234-00-00	..ROLLER, DETENT	1	

CONTINUED ON NEXT FRAME >

CONTROL 703 PULL

703 REMOTE CONTROL (PULL TO OPEN TYPE)




601R10R-R040

Ref No.	Part Number	Description	Qty	Remarks
21	703-48345-01-00	. .CABLE END, REMOTE CONTROL 2	2	
22	703-48358-00-00	. .ANCHOR, CABLE	1	
23	703-48244-00-00	. .SPRING, FREE ACCEL.	1	
24	703-48238-00-00	. .SPRING, DETENT	5	
25	703-48211-10-00	. .HOUSING,1	1	
26	703-48212-10-00	. .BACK PLATE 1	1	
27	703-48213-10-00	. .BACK PLATE 2	1	
28	703-48221-10-00	. .LEVER, CONTROL	1	
29	703-48246-00-00	. .SPACER	1	
30	703-48227-00-00	. .SPRING, NEUTRAL LOCK	1	
31	703-48222-30-00	. .GRIP, CONTROL LEVER	1	WITHOUT PT/T SW.
32	703-48223-10-00	. .LOCK, NEUTRAL	1	
33	703-48225-10-00	. .COVER	1	
34	703-48219-10-00	. .COVER, LEAD	1	
35	703-48281-00-00	. .SCREW	2	
36	703-44189-20-00	. .SCREW	7	
37	97380-08030-00	. .BOLT	1	
38	92990-08600-00	. .WASHER, PLATE	1	
39	703-48128-10-00	. .SCREW 2	3	
40	98580-04006-00	. .SCREW, PAN HEAD (+)	2	

CONTINUED ON NEXT FRAME >

CONTROL 703 PULL

703 REMOTE CONTROL (PULL TO OPEN TYPE)



601R10R-R040

Ref No.	Part Number	Description	Qty	Remarks
41	703-48129-00-00	. SCREW 3	2	
42	703-44189-30-00	..SCREW	3	
43	95380-06600-00	. NUT, HEXAGON	3	
44	703-48293-10-00	.. SPACER, REMOTE CONTROL	1	
45	701-48287-00-00	..WASHER	3	
46	703-48215-10-00	..GRAPHIC	1	
47	6X3-44191-00-00	. INDICATOR, SHIFT	1	
48	703-82510-34-00	.. MAIN SWITCH ASSY	1	
49	703-82577-00-00	.. CAP, KEY	1	
50	6K1-82532-00-00	.. CAP	1	
51	703-82531-00-00	..WIRE, LEAD (L70)	1	
52	688-82575-02-00	..ENGINE STOP SWITCH ASSY	1	
53	682-82556-00-00	.. LANYARD, STOP SWITCH	1	
54	688-82586-21-00	.. EXTENSION, WIRE HARNESS (4.9M)	1	
55	703-82540-00-00	..NEUTRAL SWITCH ASSY	1	
56	703-83383-11-00	..BUZZER	1	
57	703-48284-00-00	.. GROMMET	1	
58	703-82591-00-00	.. BAND	1	
59	703-82592-00-00	.. BAND	1	
60	703-48153-00-00	.. SHAFT, FREE ACCEL.	1	