


DBW REMOTE CONTROL 3 (TRIPLE)

6X6 REMOTE CONTROL (TRIPLE)




Ref No.	Part Number	Description	Qty	Remarks
1	6X6-48208-63-00	REMOTE CONTROL ASSY (TRIPLE)	1	NOT FOR SALE
1	6X6-48208-73-00	REMOTE CONTROL ASSY (TRIPLE)	1	NOT FOR SALE
2	6X6-82563-01-00	TRIM & TILT SWITCH ASSY	1	
3	6X6-48221-00-00	LEVER, CONTROL	2	
4	6X6-48222-00-00	GRIP, CONTROL LEVER	2	
5	6X6-48224-00-00	COVER, CONTROL LEVER	2	
6	6X6-48222-10-00	GRIP, CONTROL LEVER	1	
7	6X6-48224-10-00	COVER, CONTROL LEVER	2	
8	98580-05014-00	.SCREW, PAN HEAD	20	
9	92990-05300-00	.WASHER, INTERNAL TOOTH	2	
10	6X6-48171-00-00	.BOLT	2	
11	92990-08600-00	.WASHER, PLATE	2	
12	EL8-48127-00-00	.SCREW 1	6	
13	6X6-48119-10-00	COVER	1	
14	6X6-84301-24-00	PILOT LIGHT ASSY 1	1	
15	6X6-48215-50-00	..GRAPHIC	1	
16	6X6-48216-20-00	..GRAPHIC	1	
17	6X6-48167-10-00	PLUG	1	
18	6X6-48167-20-00	PLUG	1	
19	6X6-48167-60-00	PLUG	2	

CONTINUED ON NEXT FRAME >

DBW REMOTE CONTROL 3 (TRIPLE)

6X6 REMOTE CONTROL (TRIPLE)




Ref No.	Part Number	Description	Qty	Remarks
20	6X6-48219-10-00	COVER, LEAD	1	
21	6X6-48219-20-00	COVER, LEAD	1	
22	6X6-8259E-01-00	SWITCH ASSY	1	
23	92990-05200-00	.WASHER, PLAIN	12	
24	6X6-48176-10-00	GROMMET	1	
25	6X6-48225-00-00	COVER	1	
26	6X6-82563-41-00	TRIM & TILT SWITCH ASSY	1	
27	98580-04010-00	.SCREW, PAN HEAD	10	
28	6X6-48267-C0-00	BOLT SET	2	
29	6X6-481A0-12-00	REMO-CON. CASE ASSY	1	
30	6X6-48212-00-00	BACK PLATE 1	2	
31	6X6-48144-10-00	PLATE, STOPPER 2	2	
32	6X6-48242-02-00	SHAFT, DRIVE	1	
33	6X6-48242-12-00	SHAFT, DRIVE	1	
34	6X6-48233-01-00	GEAR 2	4	
35	6X6-48238-00-00	.SPRING, DETENT	2	
36	6X6-48237-00-00	.ADAPTOR	2	
37	6X6-48236-00-00	.ROLLER, DETENT	2	
38	6X6-48189-00-00	RETAINER	2	
39	703-48198-00-00	.WASHER, WAVE	4	

CONTINUED ON NEXT FRAME >

DBW REMOTE CONTROL 3 (TRIPLE)

6X6 REMOTE CONTROL (TRIPLE)




Ref No.	Part Number	Description	Qty	Remarks
40	6X6-48193-00-00	.WASHER 3	2	
41	6X6-48118-00-00	.CLIP, SHIFT LEVER	2	
42	6X6-48234-00-00	.BUSHING 1	2	
43	6X6-48267-00-00	.BOLT SET	2	
44	6X6-48158-00-00	.SPRING 1	2	
45	6X6-48264-00-00	.FRICTION, THROTTLE	2	
46	704-48287-00-00	.WASHER	6	
47	98580-05025-00	.SCREW, PAN HEAD	4	
48	704-48156-00-00	.NUT 1	1	
49	704-48283-00-00	.SCREW	1	
50	6X6-81147-00-00	SCREW 3	4	
51	6X6-48213-00-00	BACK PLATE 2	2	
52	6X6-48228-01-00	HOLDER, SWITCH	2	
53	6X6-85590-31-00	.CONTROL UNIT ASSY	3	
54	703-82591-00-00	.BAND	8	
55	98580-05060-00	.SCREW, PAN HEAD	4	UR
55	97780-50145-00	.SCREW, TAPPING	4	UR
56	95380-05600-00	.NUT	4	
57	6X6-48129-01-00	SCREW 3	4	
58	6X6-44191-10-00	INDICATOR, SHIFT	2	

CONTINUED ON NEXT FRAME >

DBW REMOTE CONTROL 3 (TRIPLE)

6X6 REMOTE CONTROL (TRIPLE)




Ref No.	Part Number	Description	Qty	Remarks
59	6X6-48176-50-00	GROMMET	1	
60	6X6-48176-60-00	GROMMET	1	
61	6X6-48127-01-00	SCREW 1	8	
62	6X6-48128-00-00	.SCREW 2	4	
63	6X6-81146-01-00	SCREW 2	4	
64	6X6-81145-01-00	SCREW 1	2	
65	6X6-82563-51-00	TRIM & TILT SWITCH ASSY	1	
66	6X6-82563-61-00	TRIM & TILT SWITCH ASSY	1	
67	6X6-8259F-10-00	SWITCH ASSY	1	
68	6X6-481A0-32-00	REMO-CON. CASE ASSY	1	
69	98780-05010-00	SCREW, FLAT HEAD	2	
70	6X6-48211-10-00	.HOUSING,1	1	
71	6X6-85557-00-00	.HOLDER	2	
72	6X6-82591-00-00	.BAND	2	
73	6X6-8252S-00-00	.SPACER, 1	2	
74	6X6-82584-00-00	.CLAMP	1	
75	6X6-82581-00-00	.STAY, CORD CLAMP	2	
76	6X7-48127-00-00	.SCREW 1	1	
77	6X0-48128-00-00	.SCREW(M6X30)	4	
78	704-81950-10-00	.RELAY ASSY	4	

CONTINUED ON NEXT FRAME >

DBW REMOTE CONTROL 3 (TRIPLE)

6X6 REMOTE CONTROL (TRIPLE)



Ref No.	Part Number	Description	Qty	Remarks
79	6X6-82540-00-00	.NEUTRAL SWITCH ASSY	1	
80	6X6-48241-00-00	.ARM, DRIVE	2	
81	6X6-48245-01-00	.PLATE, LOCK	2	
82	6X6-82545-00-00	GROMMET	2	
83	6X6-8252V-00-00	.SCREW, SPECIAL	4	
84	6X6-82540-10-00	NEUTRAL SWITCH ASSY	1	
85	703-82591-10-00	BAND	8	