


VAPOR SEPARATOR 1



Ref No.	Part Number	Description	Qty	Remarks
1	6FP-14180-02-00	FLOAT CHAMBER ASSY	1	
2	6FP-14960-00-00	BODY ASSY	1	
3	6FP-24452-00-00	..COVER, COOLER	1	
4	6FP-24462-00-00	..GASKET, COOLER	1	
5	6FP-14591-00-00	..SCREW	6	
6	6C5-14191-00-00	..PLUG, DRAIN	1	
7	63P-11325-21-00	..ANODE	1	
8	6FP-24444-00-00	..SCREW	1	
9	6FP-14182-00-00	COVER, FLOAT CHAMBER	1	
10	6FP-13910-00-00	..FUEL PUMP ASSY	1	
11	6FP-13907-00-00	...FUEL PUMP COMP.	1	
12	6FP-13915-00-00	...FILTER	1	
13	6FP-14985-00-00	..FLOAT	1	
14	6FP-13906-00-00	..REGULATOR, PRESSURE	1	
15	6FP-87226-00-00	..WIRE HARNESS ASSY	1	
16	6FP-13593-01-00	DAMPER	1	
17	6FP-14984-00-00	GASKET, FLOAT CHAMBER	1	
18	6C5-14567-00-00	SCREW	8	
19	90387-06M03-00	COLLAR	4	
20	69L-85516-01-00	SPACER	4	