


REMOTE CONTROL ASSY 4

704 REMOTE CONTROL (SINGLE)




601R10R-R070

Ref No.	Part Number	Description	Qty	Remarks
1	704-48205-R2-00	REMOTE CONTROL ASSY (R/H)	1	UR FOR SINGLE WITH PT/T SW.
1	704-48206-R2-00	REMOTE CONTROL ASSY (L/H)	1	UR FOR SINGLE WITH PT/T SW.
2	704-48129-11-00	..SCREW 3	3	
3	EL8-48251-00-00	..PLATE, CAM	1	
4	704-48265-00-00	..SHAFT, FRICTION	1	
5	701-48246-00-00	..SPACER	1	
6	93430-06024-00	..CIRCLIP	4	
7	EL8-48259-00-00	..CIRCLIP 1	1	
8	704-48262-00-00	..SHAFT, THROTTLE	1	
9	704-48264-00-00	..THROTTLE, FRICTION	1	
10	704-82540-40-00	..NEUTRAL SWITCH ASSY	1	
11	704-48119-50-00	..COVER	1	
12	EL8-48281-00-00	..SCREW	1	
13	704-48215-61-00	..GRAPHIC	1	
14	704-48281-00-00	..SCREW	1	
15	97890-05025-00	..SCREW, PAN HEAD	2	
16	704-48261-00-00	..ARM, THROTTLE	1	
17	EL8-48191-00-00	..WASHER 1	1	
18	704-48283-00-00	..SCREW	4	
19	97380-06018-00	..BOLT	3	

CONTINUED ON NEXT FRAME >

REMOTE CONTROL ASSY 4

704 REMOTE CONTROL (SINGLE)




601R10R-R070

Ref No.	Part Number	Description	Qty	Remarks
20	703-48345-01-00	..CABLE END, REMOTE CONTROL 2	2	
21	704-48287-00-00	..WASHER	4	
22	95380-05600-00	..NUT	4	
23	704-48271-00-00	..ARM, SHIFT	1	
24	EL8-48127-00-00	..SCREW 1	10	
25	703-48358-01-00	..ANCHOR, CABLE	1	
26	704-48231-00-00	..HOUSING, GEAR	1	
27	EL8-48241-00-00	..ARM, DRIVE	1	
28	EL8-48254-00-00	..STOPPER, THROTTLE ADJUSTING	1	
29	92780-06020-00	..SCREW, FLAT HEAD	2	
30	98780-05018-00	..SCREW, FLAT HEAD	4	
31	EL8-48244-00-00	..SPRING, FREE ACCEL.	1	
32	EL8-48245-00-00	..PLATE, LOCK	1	
33	704-48222-10-00	..GRIP, CONTROL LEVER	1	
34	704-82594-00-00	..CLAMP	1	
35	704-82563-60-00	..TRIM & TILT SWITCH ASSY	1	
36	704-48229-30-00	..GRIP, CONTROL LEVER	1	
37	92990-05300-00	..WASHER, INTERNAL TOOTH	3	
38	95380-06600-00	..NUT, HEXAGON	2	
39	701-48248-00-00	..ROLLER, FREE ACCEL.	1	

CONTINUED ON NEXT FRAME >

REMOTE CONTROL ASSY 4

704 REMOTE CONTROL (SINGLE)




601R10R-R070

Ref No.	Part Number	Description	Qty	Remarks
40	704-48238-00-00	..SPRING, DETENT	5	
41	704-48232-P1-00	..GEAR	1	
42	EL8-48164-00-00	..PIN 2	1	
43	704-48221-R0-00	..LEVER, CONTROL	1	
44	704-48242-10-00	..SHAFT, DRIVE	1	
45	704-48225-R0-00	..COVER	1	
46	704-48192-00-00	..WASHER 2	1	
47	97890-06018-00	..SCREW, PAN HEAD	2	
48	92990-06300-00	..WASHER, INTERNAL TOOTH	2	
49	704-48224-R0-00	..COVER, CONTROL LEVER	1	
50	EL8-48279-00-00	..CIRCLIP 2	1	
51	704-48234-00-00	..BUSHING 1	1	
52	704-48219-R0-00	..COVER, LEAD	1	
53	704-48144-10-00	..PLATE, STOPPER 2	2	
54	704-48176-01-00	..GROMMET	1	
55	704-48192-P0-00	..WASHER 2	1	
56	704-48233-00-00	..GEAR 2	1	
57	704-48235-00-00	..BUSHING	1	
58	704-48153-00-00	..SHAFT, FREE ACCEL.	1	
59	704-48166-00-00	..PLUG	1	

CONTINUED ON NEXT FRAME >

REMOTE CONTROL ASSY 4

704 REMOTE CONTROL (SINGLE)



Ref No.	Part Number	Description	Qty	Remarks
60	704-48284-P0-00	..GROMMET	1	
61	704-48178-10-00	..PLATE, SHIFT	1	
62	704-48167-20-00	..PLUG	1	
63	97890-05016-00	..SCREW, PAN HEAD	3	