



# STARTING MOTOR



Ref No.	Part Number	Description	Qty	Remarks
1	6EM-81800-02-00	STARTING MOTOR ASSY	1	
2	67F-81850-00-00	..ARMATURE ASSY	1	
3	67F-81810-00-00	..STATOR ASSY	1	
4	69J-81840-11-00	..BRUSH HOLDER ASSY	1	
5	69J-81801-11-00	...BRUSH SET	1	
6	67F-81813-00-00	...SPRING, BRUSH	4	
7	6CB-81820-00-00	..REAR BRACKET ASSY	1	
8	6CB-81807-00-00	..GEAR ASSY, STARTING MOTOR	1	
9	6CB-81832-00-00	...CLUTCH, OVER RUN	1	
10	6CB-81836-00-00	...SHAFT, PINION	1	
11	67F-81821-00-00	...BRACKET, CENTER 1	1	
12	67F-81841-00-00	... ..BEARING	1	
13	67F-8183R-00-00	... ..GASKET	1	
14	6CB-81809-00-00	...WASHER KIT	1	
15	67F-81891-00-00	..GEAR, RING	1	WITH 67F-8183R-00
16	67F-81830-00-00	..BRACKET, CENTER 2	1	
17	60V-8183T-00-00	..GEAR, IDLER	3	
18	6CB-81842-00-00	..COVER	1	
19	6C5-81839-00-00	..LEVER ASSY	1	
20	6EM-81941-01-00	..STARTER RELAY ASSY	1	

CONTINUED ON NEXT FRAME >

# STARTING MOTOR



Ref No.	Part Number	Description	Qty	Remarks
21	6C5-81869-00-00	..COVER, DUST	1	
22	6CB-81826-00-00	..BOLT	2	
23	69J-81828-00-00	..BOLT 2	2	
24	67F-81846-00-00	..SCREW	2	