


## INTAKE 3

Ref No.	Part Number	Description	Qty	Remarks
1	63P-14200-8A-00	INTAKE ASSY	1	
2	63P-13751-21-00	BODY, THROTTLE 1	1	
3	69J-14321-00-00	..SCREW, THROTTLE	1	
4	68V-14331-00-00	..SPRING, THROTTLE VALVE	3	
5	68V-14323-00-00	..SCREW, AIR ADJUSTING	1	
6	6S1-85885-01-00	..THROTTLE SENSOR ASSY	1	
7	68V-81145-01-00	..SCREW 1	2	
8	68V-8182L-00-00	..O-RING 1	1	
9	68V-14356-00-00	..WASHER, SPRING	1	
10	68V-14565-00-00	..SCREW	8	
11	63P-14291-00-00	BRACKET 1	1	
12	63P-13641-10-00	MANIFOLD, INTAKE 1	1	
13	63P-14496-00-00	BOLT	6	
14	97E95-06516-00	BOLT, HEXAGON W/W DEEP RECESS	4	
15	63P-13645-00-00	GASKET, MANIFOLD 1	4	
16	6H4-41237-00-00	JOINT, LINK	1	
17	95380-05700-00	NUT	1	
18	682-41238-01-00	JOINT, LINK	1	
19	63P-13557-00-00	GASKET	2	
20	6P2-14446-00-00	BOLT	2	

CONTINUED ON NEXT FRAME >

# INTAKE 3



Ref No.	Part Number	Description	Qty	Remarks
21	63P-13643-00-00	COVER, MANIFOLD	4	
22	63P-13761-02-00	INJECTOR	4	
23	68V-1416A-00-00	. .O-RING	1	
24	68V-13766-00-00	RUBBER, INJECTOR	4	
25	63P-1312A-02-00	VALVE, CONTROL	1	
26	68V-81146-01-00	SCREW 2	3	
27	63P-82380-00-00	SENSOR, PRESSURE	1	
28	68V-81147-00-00	SCREW 3	2	
29	63P-14292-00-00	BRACKET 2	1	