

BRACKET 5

Ref No.	Part Number	Description	Qty	Remarks
1	6LH-43676-00-8D	HOOK	1	
2	93608-16M16-00	PIN, DOWEL	2	
3	90110-08133-00	BOLT, HEXAGON SOCKET HEAD	6	
4	6LH-85888-00-00	SENSOR ANGLE	1	
5	6LH-85888-10-00	SENSOR ANGLE	1	
6	6LH-60428-00-00	MAGNET, SENSOR	2	
7	97980-04210-00	SCREW, WITH WASHER	4	
8	6LH-45821-00-00	STAY 1	1	
9	6LH-44194-01-00	CAP	2	
10	6LH-86016-00-00	COVER, SENSOR	1	
11	90105-06235-00	BOLT, FLANGE	3	
12	93606-12019-00	.PIN, DOWEL	2	
13	93410-30101-00	CIRCLIP	2	
14	90201-31008-00	WASHER, PLATE	2	
15	90387-30015-00	COLLAR	2	
16	93210-29282-00	O-RING	2	
17	90202-31001-00	WASHER, PLATE	2	
18	6LH-48133-00-00	PLATE, LINK	1	
19	93700-06002-00	NIPPLE, GREASE	2	

