



# FUEL INJECTION PUMP



Ref No.	Part Number	Description	Qty	Remarks
1	6FM-14180-02-00	FLOAT CHAMBER ASSY	1	
2	6FM-14182-00-00	..COVER, FLOAT CHAMBER	1	
3	6FM-14181-01-00	..BODY, FLOAT CHAMBER 1	1	
4	6FM-13906-00-00	..REGULATOR, PRESSURE	1	
5	6FM-14146-00-00	..PLATE	1	
6	6FM-14565-00-00	..SCREW	2	
7	6FM-14567-00-00	..SCREW	8	
8	6FM-14243-00-00	..PLATE	1	
9	6FM-14984-00-00	..GASKET, FLOAT CHAMBER	1	
10	6FM-21841-00-00	..COOLER	1	
11	6FM-14562-00-00	..O-RING	4	
12	6FM-14546-00-00	..VALVE, NEEDLE	1	
13	68V-14985-00-00	..FLOAT	1	
14	6FM-14386-00-00	..PIN, FLOAT	1	
15	6FM-14565-00-00	..SCREW	1	
16	6FM-14674-00-00	..VALVE, PLATE	1	
17	6FM-13910-00-00	..FUEL PUMP ASSY	1	
18	6FM-14561-00-00	...O-RING	1	
19	6FM-13915-00-00	..FILTER	1	
20	6FM-1469M-00-00	..WIRE 1	1	

CONTINUED ON NEXT FRAME >

# FUEL INJECTION PUMP



Ref No.	Part Number	Description	Qty	Remarks
21	6FM-1469N-00-00	. .WIRE 2	1	
22	6FM-14137-00-00	. .CLIP	1	
23	6FM-13781-00-00	. .DAMPER, PUMP	1	
24	6FM-13593-00-00	DAMPER	3	
25	90387-06M69-00	COLLAR	1	
26	90387-06176-00	COLLAR	3	
27	90119-06291-00	BOLT, WITH WASHER	2	
28	90101-06032-00	BOLT	1	
29	67F-13448-00-00	CAP	1	