



VALVE

| Ref No. | Part Number | Description | Qty | Remarks |
|---------|-----------------|-----------------------------|-----|---------|
| 1 | 6FM-12111-00-00 | VALVE, INTAKE | 2 | |
| 2 | 6FM-12121-00-00 | VALVE, EXHAUST | 2 | |
| 3 | 62Y-12116-00-00 | SEAT, VALVE SPRING | 4 | |
| 4 | 3YF-12113-00-00 | SPRING, VALVE INNER | 4 | |
| 5 | 30X-12117-00-00 | RETAINER, VALVE SPRING | 4 | |
| 6 | 30X-12118-00-00 | LOCK, VALVE SPRING RETAINER | 8 | |
| 7 | 51Y-12119-00-00 | SEAL, VALVE STEM | 4 | |
| 8 | 66M-12146-00-00 | SHAFT, ROCKER | 1 | |
| 9 | 90119-06054-00 | BOLT, WITH WASHER | 1 | |
| 10 | 90387-13006-00 | COLLAR | 2 | |
| 11 | 90501-120A5-00 | SPRING, COMPRESSION | 2 | |
| 12 | 90201-131M4-00 | WASHER, PLATE | 2 | |
| 13 | 6AH-12151-01-00 | ARM, VALVE ROCKER | 1 | |
| 14 | 64J-12159-00-00 | SCREW, VALVE ADJUSTING | 1 | |
| 15 | 62Y-12158-00-00 | NUT, LOCK | 1 | |
| 16 | 6FM-12151-00-00 | ARM, VALVE ROCKER | 3 | |
| 17 | 6C5-12159-00-00 | SCREW, VALVE ADJUSTING | 3 | |
| 18 | 6C5-12158-00-00 | NUT, LOCK | 3 | |